Nikon

DIGITAL CAMERA

# COOLPIX S200

## User's Manual

En

# Where to Find It

Find what you're looking for from


| | |
|---|---|
| Q The *Table of Contents* | vii – x |
| Find items by function or menu name. | |
| Q The *Q&A Index* | xi – xii |
| Know what you want to do but don't know the function name? Find it from the "question and answer" index. | |
| Q The *Index* | 132 – 134 |
| Search by key word. | |
| Q Error Messages | 119 – 122 |
| If a warning is displayed in the monitor, find the solution here. | |
| Q Troubleshooting | 123 – 127 |
| Camera behaving unexpectedly? Find the solution here. | |


### Help

Use the camera's on-board help feature for help on menu items and other topics. See page 11 for details.

### Trademark Information


- Microsoft and Windows are registered trademarks of Microsoft Corporation.
- Macintosh, Mac OS, and QuickTime are registered trademarks of Apple Computer, Inc.
- Adobe and Acrobat are registered trademarks of Adobe Systems Inc.
- The SD logo is a trademark of the SD Card Association.
- PictBridge is a trademark.
- D-Lighting technology is provided by Apical Limited.
- All other trade names mentioned in this manual or the other documentation provided with your Nikon product are trademarks or registered trademarks of their respective holders.

Introduction

First Steps

Basic Photography and Playback: Auto Mode

High-sensitivity Shooting Mode

Scene Mode

Anti-shake Mode

One-Touch Portrait Mode

More on Playback

Movies

Voice Recordings

Connecting to Televisions, Computers, and Printers

MENU Shooting, Playback, and Setup Menus

Technical Notes

# For Your Safety



To prevent damage to your Nikon product or injury to yourself or to others, read the following safety precautions in their entirety before using this equipment. Keep these safety instructions where all those who use the product will read them.

The consequences that could result from failure to observe the precautions listed in this section are indicated by the following symbol:

This icon marks warnings, information that should be read before using this Nikon product to prevent possible injury.

## WARNINGS

### ⚠ Turn off in the event of malfunction

Should you notice smoke or an unusual smell coming from the camera or optional AC adapter, unplug the AC adapter and/ or remove the battery immediately, taking care to avoid burns. Continued operation could result in injury. After removing or disconnecting the power source, take the equipment to a Nikon-authorized service representative for inspection.

### ⚠ Do not disassemble

Touching the internal parts of the camera or AC adapter could result in injury. Repairs should be performed only by qualified technicians. Should the camera or AC adapter break open as the result of a fall or other accident, take the product to a Nikon-authorized service representative for inspection after unplugging the product and/or removing the battery.

### ⚠ Do not use the camera or AC adapter in the presence of flammable gas

Do not use electronic equipment in the presence of flammable gas, as this could result in explosion or fire.

### ⚠ Handle the camera strap with care

Never place the strap around the neck of an infant or child.

### ⚠ Keep out of reach of children

Particular care should be taken to prevent infants from putting the battery or other small parts into their mouths.

**⚠ Observe caution when handling the battery**

The battery may leak or explode if improperly handled. Observe the following precautions when handling the battery for use in this product:

- Before replacing the battery, turn the product off. If you are using the AC adapter, be sure it is unplugged.
- Only use a Rechargeable Li-ion Battery EN-EL10 (supplied). Charge the battery by inserting it in a Battery Charger MH-63 (supplied).
- When inserting the battery, do not attempt to insert it upside down or backwards.
- Do not short or disassemble the battery or attempt to remove or break the battery insulation or casing.
- Do not expose the battery to flame or to excessive heat.
- Do not immerse in or expose to water.
- Replace the terminal cover when transporting the battery. Do not transport or store with metal objects such as necklaces or hairpins.
- The battery is prone to leakage when fully discharged. To avoid damage to the product, be sure to remove the battery when no charge remains.
- Discontinue use immediately should you notice any change in the battery, such as discoloration or deformation.
- If liquid from the damaged battery comes in contact with clothing or skin, rinse immediately with plenty of water.

**⚠ Observe the following precautions when handling the battery charger**

- Keep dry. Failure to observe this precaution could result in fire or electric shock.
- Dust on or near the metal parts of the plug should be removed with a dry cloth. Continued use could result in fire.
- Do not handle the power cable or go near the battery charger during thunderstorms. Failure to observe this precaution could result in electric shock.
- Do not damage, modify, forcibly tug or bend the power cable, place it under heavy objects, or expose it to heat or flame. Should the insulation be damaged and the wires become exposed, take it to a Nikon-authorized service representative for inspection. Failure to observe these precautions could result in fire or electric shock.

- Do not handle the plug or battery charger with wet hands. Failure to observe this precaution could result in electric shock.

**⚠ Use appropriate cables**

When connecting cables to the input and output jacks, use only the cables provided or sold by Nikon for the purpose, to maintain compliance with product regulations.

**⚠ Handle moving parts with care**

Be careful that your fingers or other objects are not pinched by the lens cover or other moving parts.

**⚠ CD-ROMs**

The CD-ROMs supplied with this device should not be played back on audio CD equipment. Playing CD-ROMs on an audio CD player could cause hearing loss or damage the equipment.

**⚠ Observe caution when using the flash**

Using the flash close to your subject's eyes could cause temporary visual impairment. Particular care should be observed if photographing infants, when the flash should be no less than one meter (39 in.) from the subject.

**⚠ Do not operate the flash with the flash window touching a person or object**

Failure to observe this precaution could result in burns or fire.

**⚠ Avoid contact with liquid crystal**

Should the monitor break, care should be taken to avoid injury caused by broken glass and to prevent liquid crystal from the monitor touching the skin or entering the eyes or mouth.

## Notice for Customers in the U.S.A.

### Federal Communications Commission (FCC) Radio Frequency Interference Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/television technician for help.

FC Nikon
COOLPIX S200

### CAUTIONS

#### Modifications

The FCC requires the user to be notified that any changes or modifications made to this device that are not expressly approved by Nikon Corporation may void the user's authority to operate the equipment.

#### Interface Cables

Use the interface cables sold or provided by Nikon for your equipment. Using other interface cables may exceed the limits of Class B Part 15 of the FCC rules.

### Notice for customers in the State of California

**WARNING**: Handling the cord on this product will expose you to lead, a chemical known to the State of California to cause birth defects or other reproductive harm. ***Wash hands after handling***.

Nikon Inc.,
1300 Walt Whitman Road
Melville, New York 11747-3064
USA
Tel: 631-547-4200

## Notice for customers in Canada

**CAUTION**

This Class B digital apparatus complies with Canadian ICES-003.

**ATTENTION**

Cet appareil numérique de la classe B est conforme à la norme NMB-003 du Canada.

## Symbol for Separate Collection in European Countries

This symbol indicates that this product is to be collected separately.

The following apply only to users in European countries:

- This product is designated for separate collection at an appropriate collection point. Do not dispose of as household waste.
- For more information, contact the retailer or the local authorities in charge of waste management.

# Table of Contents


Introduction ..... ii
For Your Safety ..... ii
WARNINGS ..... ii
Notices ..... v
Q&A Index ..... xi
About This Manual ..... 1
Information and Precautions ..... 2
Parts of the Camera ..... 4
Attaching the Camera Strap ..... 4
The Monitor ..... 6
Shooting ..... 6
Playback ..... 7
Basic Operations ..... 8
The ▶ (shooting/playback) Button ..... 8
The MODE (mode) Button ..... 8
The MENU Button ..... 9
Turning On and Off the Camera ..... 11
Help Displays ..... 11

First Steps ..... 12
Charging the Battery ..... 12
Inserting the Battery ..... 14
Removing the Battery ..... 15
Setting Display Language, Date, and Time ..... 16
Inserting Memory Cards ..... 18
Removing Memory Cards ..... 19

📷 Basic Photography and Playback: Auto Mode ..... 20
Step 1 Turn the Camera On and Select 📷 (Auto) Mode ..... 20
Step 2 Frame a Picture ..... 22
Step 3 Focus and Shoot ..... 24
Step 4 Viewing and Deleting Pictures ..... 26
Using the Flash ..... 28
Taking Pictures with the Self-Timer ..... 30
Macro Close-up Mode ..... 31
Exposure Compensation ..... 32

Hi ISO High-sensitivity Shooting Mode ..... 33
Shooting in High-sensitivity Shooting Mode ..... 33

SCENE Scene Mode ..... 34
Shooting in Scene Modes ..... 34
Features ..... 35

Anti-shake Mode ..... 42
Shooting in Anti-shake Mode ..... 42

One-Touch Portrait Mode ..... 43
Taking Pictures in the One-Touch Portrait Mode ..... 43
The One-Touch Portrait Menu ..... 44

More on Playback ..... 45
Viewing Multiple Pictures: Thumbnail Playback ..... 45
Taking a Closer Look: Playback Zoom ..... 46
Editing Pictures ..... 47
Enhancing Brightness and Contrast: D-Lighting ..... 48
Compensating Blurred Images: Electronic VR ..... 49
Creating a Cropped Copy: Crop ..... 50
Resizing Pictures: Small Picture ..... 51
Voice Memos: Recording and Playback ..... 52
Viewing Pictures by Date ..... 54

Movies ..... 58
Recording Movies ..... 58
The Movie Menu ..... 59
Selecting Movie Options ..... 60
Auto-Focus Mode ..... 61
Electronic VR ..... 61
Time-Lapse Movies ..... 62
Stop-Motion Movies ..... 63
Movie Playback ..... 64
Deleting Movie Files ..... 64

Voice Recordings ..... 65
Making Voice Recordings ..... 65
Playing Voice Recordings ..... 67
Copying Voice Recordings ..... 69

Connecting to Televisions, Computers, and Printers ..... 70
Connecting to a TV ..... 70
Connecting to a Computer ..... 71
Before Connecting the Camera ..... 71
Setting the USB Option ..... 72
Transferring Pictures to a Computer ..... 73
Connecting to a Printer ..... 75
Connecting the Camera and Printer ..... 76
Printing Pictures One at a Time ..... 77
Printing Multiple Pictures ..... 78
Creating a DPOF Print Order: Print Set ..... 81

MENU Shooting, Playback, and Setup Menus ..... 83
Shooting Options: The Shooting Menu ..... 83
Displaying the Shooting Menu and High-sensitivity Menu ..... 84
Image Mode ..... 84
WB White Balance ..... 86
Continuous ..... 88
BSS Best Shot Selector (BSS) ..... 90
ISO ISO Sensitivity ..... 91
Color Options ..... 91
VR Electronic VR ..... 92
Restrictions on Camera Settings ..... 93
Playback Options: The Playback Menu ..... 94
Displaying the Playback Menu ..... 94
D-Lighting ..... 48
Print set ..... 81
Slide Show ..... 96
Delete ..... 97
Protect ..... 98
Transfer Marking ..... 98
Small pic. ..... 51
Voice memo ..... 52
Copy ..... 99
Basic Camera Setup: The Setup Menu ..... 100
Displaying the Setup Menu ..... 101
MENU Menus ..... 101
Quick Startup ..... 102
Welcome Screen ..... 102
Date ..... 103
Monitor Settings ..... 106

Date Imprint ..... 107
Sound Settings ..... 109
Auto Off ..... 109
Format Memory/Format Card ..... 110
Language ..... 111
Interface ..... 111
Reset All ..... 112
Firmware Version ..... 113

**Technical Notes ..... 114**
**Optional Accessories ..... 114**
Approved Memory Cards ..... 114
**Image/Sound File and Folder Names ..... 115**
**Caring for the Camera ..... 116**
Cleaning ..... 118
Storage ..... 118
**Error Messages ..... 119**
**Troubleshooting ..... 123**
**Specifications ..... 128**
**Supported Standards ..... 131**
**Index ..... 132**

# Q&A Index

Find what you're looking for using this "question and answer" index.



## General Questions

| Question | Key phrase | |
|---|---|---|
| What do these indicators mean? | Monitor | 6–7 |
| What does this warning mean? | Error messages and displays | 119–122 |
| How do I use the menus? | Using the menus | 9 |
| How do I get more information on a menu? | Help | 11 |
| How much charge does the battery have left? | Battery level | 20 |
| What accessories are available for my camera? | Optional accessories | 114 |
| What memory cards can I use? | Approved memory Cards | 114 |
| How do I clean the camera? | Cleaning the camera | 118 |

## Camera Setup

| Question | Key phrase | |
|---|---|---|
| How do I keep the monitor from turning off? | Auto off | 109 |
| How do I adjust monitor brightness? | Brightness | 106 |
| How do I set the clock? | World time | 16, 103 |
| How do I set the clock for daylight savings time? | World time | 16, 104 |
| How do I change time zones when I travel? | World time | 103 |
| How do I restore default settings? | Reset all | 112 |
| Can I display the menus in a different language? | Language | 111 |
| Can I display the menus in different style? | Menus | 101 |
| How do I keep the camera from beeping? | Sound Settings | 109 |

## Taking Photographs

| Question | Key phrase | |
|---|---|---|
| Is there an easy way to take snapshots? | (Auto) mode | 20 |
| Is there an easy way to take more creative shots? | SCENE (Scene) mode | 34 |
| How can I avoid blur with the camera zoomed in? | ((✋)) (Anti-shake) mode | 42 |
| How can I avoid blur when lighting is poor? | HI ISO (High-sensitivity) mode | 33 |

| | | |
|---|---|---|
| How can I focus on the faces of the subjects automatically? | (One-touch portrait) mode | 43 |
| How do I record and play movies? | Movies | 58 |
| How do I use flash? | Flash mode | 28 |
| How do I use self-timer? | Self-timer | 30 |
| Can I focus on nearby objects? | Macro close-up mode, (close up) mode | 31, 38 |
| How do I take bigger photographs? | Image mode | 84 |
| How can I get more photos on the memory card? | Image mode | 84 |

## Viewing, Printing, and Retouching Photographs

| Question | Key phrase | |
|---|---|---|
| Can I view my photographs on the camera? | Camera playback | 26, 45 |
| How do I get rid of an unwanted photo? | Deleting pictures | 26 |
| Can I delete several photos at once? | Delete | 97 |
| Can I zoom in on pictures to make sure they're in focus? | Playback zoom | 27, 46 |
| Can I protect photos from accidental deletion? | Protect | 98 |
| How do I bring out details in shadows? | D-Lighting | 48 |
| Can I compensate blurred pictures? | Electronic VR | 49 |
| Can I crop pictures? | Crop | 50 |
| Can I copy pictures at a smaller size? | Small picture | 51 |
| Can I view picture by date? | Calendar mode, List by Date mode | 54, 55 |
| Can I view my photos on TV? | Television playback | 70 |
| How do I copy photos to my computer? | Connecting to a computer | 71 |
| Can I print photos without a computer? | PictBridge | 75 |
| Can I print the date on my photographs? | Printing the Date of Recording on Pictures | 82,107 |
| How do I order professional prints? | Printing photographs, Print set | 75, 81 |

# About This Manual

Thank you for your purchase of a Nikon COOLPIX S200 digital camera. This manual has been written to help you enjoy taking pictures with your Nikon digital camera. Read this manual thoroughly before use, and keep it where all those who use the product will read it.



### Symbols and Conventions

To make it easier to find the information you need, the following symbols and conventions are used:

This icon marks cautions, information that should be read before use to prevent damage to the camera.

This icon marks tips, additional information that may be helpful when using the camera.

This icon marks notes, information that should be read before using the camera.

This icon indicates that more information is available elsewhere in this manual or in the *Quick Start Guide*.

### Notations

- A Secure Digital (SD) memory card is referred to as a "memory card."
- The setting at the time of purchase is referred to as the "default setting."
- Menu items, options, and messages displayed in the camera monitor are shown in brackets ([ ]).

### Screen Samples

In this manual, images are sometimes omitted from monitor display samples so that monitor indicators can be more clearly shown.

### Illustrations and Screen Display

Illustrations and text displays shown in this manual may differ from actual display.

### Memory Cards

Pictures taken with this camera can be stored in the camera's internal memory or on removable memory cards. If a memory card is inserted, all new pictures will be stored on the memory card and delete, playback, and format operations will apply only to the pictures on the memory card. The memory card must be removed before the internal memory can be formatted or used to store, delete, or view pictures.

## Life-Long Learning

As part of Nikon's "Life-Long Learning" commitment to ongoing product support and education, continually updated information is available online at the following sites:

- For users in the U.S.A.: *http://www.nikonusa.com/*
- For users in Europe and Africa: *http://www.europe-nikon.com/support/*
- For users in Asia, Oceania, and the Middle East: *http://www.nikon-asia.com/*

Visit these sites to keep up-to-date with the latest product information, tips, answers to frequently asked questions (FAQs), and general advice on digital imaging and photography. Additional information may be available from the Nikon representative in your area. See the URL below for contact information:

*http://nikonimaging.com/*

## Use Only Nikon Brand Electronic Accessories

Nikon COOLPIX cameras are designed to the highest standards and include complex electronic circuitry. Only Nikon brand electronic accessories (including battery chargers, batteries, and AC chargers) certified by Nikon specifically for use with this Nikon digital camera are engineered and proven to operate within the operational and safety requirements of this electronic circuitry.

THE USE OF NON-NIKON ELECTRONIC ACCESSORIES COULD DAMAGE THE CAMERA AND MAY VOID YOUR NIKON WARRANTY.

For more information about Nikon brand accessories, contact a local authorized Nikon dealer.

* **Holographic seal**: Identifies this device as an authentic Nikon product.




Rechargeable Li-ion Battery EN-EL10

## Before Taking Important Pictures

Before taking pictures on important occasions (such as at weddings or before taking the camera on a trip), take a test shot to ensure that the camera is functioning normally. Nikon will not be held liable for damages or lost profits that may result from product malfunction.

## About the Manuals

- No part of the manuals included with this product may be reproduced, transmitted, transcribed, stored in a retrieval system, or translated into any language in any form, by any means, without Nikon's prior written permission.
- Nikon reserves the right to change the specifications of the hardware and software described in these manuals at any time and without prior notice.
- Nikon will not be held liable for any damages resulting from the use of this product.
- While every effort has been made to ensure that the information in these manuals is accurate and complete, we would appreciate it were you to bring any errors or omissions to the attention of the Nikon representative in your area (address provided separately).

## Notice Concerning Prohibition of Copying or Reproduction

Note that simply being in possession of material that has been digitally copied or reproduced by means of a scanner, digital camera or other device may be punishable by law.

- **Items prohibited by law from being copied or reproduced**
  Do not copy or reproduce paper money, coins, securities, government bonds, or local government bonds, even if such copies or reproductions are stamped "Sample".
  The copying or reproduction of paper money, coins, or securities which are circulated in a foreign country is prohibited.
  Unless the prior permission of the government has been obtained, the copying or reproduction of unused postage stamps or post cards issued by the government is prohibited.
  The copying or reproduction of stamps issued by the government and of certified documents stipulated by law is prohibited.
- **Cautions on certain copies and reproductions**
  The government has issued cautions on copies or reproductions of securities issued by private companies (shares, bills, checks, gift certificates, etc.), commuter passes, or coupon tickets, except when a minimum of necessary copies are to be provided for business use by a company. Also, do not copy or reproduce passports issued by the government, licenses issued by public agencies and private groups, ID cards, and tickets, such as passes and meal coupons.
- **Comply with copyright notices**
  The copying or reproduction of copyrighted creative works such as books, music, paintings, woodcut prints, maps, drawings, movies, and photographs is governed by national and international copyright laws. Do not use this product for the purpose of making illegal copies or to infringe copyright laws.

## Disposing of Data Storage Devices

Please note that deleting images or formatting data storage devices such as memory cards or built-in camera memory does not completely erase the original image data. Deleted files can sometimes be recovered from discarded storage devices using commercially available software, potentially resulting in the malicious use of personal image data. Ensuring the privacy of such data is the user's responsibility.

Before discarding a data storage device or transferring ownership to another person, erase all data using commercial deletion software, or format the device and then completely refill it with images containing no private information (for example, pictures of empty sky). Be sure to also replace any pictures selected for the welcome screen (102). Care should be taken to avoid injury or damage to property when physically destroying data storage devices.

# Parts of the Camera




| | | | |
|---|---|---|---|
| 1 | Self-timer lamp..... 30, 117 | 6 | Lens ..... 116, 128 |
| 2 | Shutter-release button..... 24 | 7 | Eyelet for camera strap |
| 3 | Power-on lamp ..... 20, 109 | 8 | Built-in microphone..... 52, 58, 65 |
| 4 | Power switch ..... 20 | 9 | Speaker..... 53, 64, 67 |
| 5 | Built-in flash..... 28 | 10 | Lens cover |

## Attaching the Camera Strap






| | |
|---|---|
| 1 | Flash lamp ..... 29 |
| 2 | Zoom buttons ..... 23<br>*See also*:<br>• **W** (wide) ..... 23<br>• **T** (tele) ..... 23<br>• (thumbnail playback) ..... 45<br>• (playback zoom) ..... 46<br>• **(help)** ..... 11 |
| 3 | (shooting/playback) button ..... 8, 26 |
| 4 | MODE (mode) button ..... 8 |
| 5 | MENU button ..... 9, 84, 94 |
| 6 | (delete) button ..... 26, 53, 64, 68 |
| 7 | Monitor ..... 6, 7, 106 |
| 8 | Cable connector ..... 70, 73, 76 |
| 9 | Tripod socket |
| 10 | Connector cover/Power connector cover (when the optional ACadapter is connected) ..... 114 |
| 11 | Battery-chamber/memory card slot cover ..... 14, 18 |
| 12 | Battery chamber ..... 14 |
| 13 | Memory card slot ..... 18 |
| 14 | Battery latch ..... 14, 15 |

# The Monitor

The following indicators may appear in the monitor during shooting and playback (actual display varies with current camera settings).



## Shooting




| | | | |
|---|---|---|---|
| 1 | Shooting mode* ..... 20, 33, 34, 42, 43, 58 | 12 | "Date not set" indicator ..... 119<br>Time zone indicator ..... 103 |
| 2 | Exposure lock ..... 41 | 13 | Date imprint ..... 107 |
| 3 | Macro close-up mode ..... 31 | 14 | Number of exposures remaining (still pictures) ..... 20, 85<br>Movie length ..... 58, 60 |
| 4 | Zoom indicator ..... 23, 31 | 15 | Focus area ..... 24 |
| 5 | Focus indicator ..... 24 | 16 | Exposure compensation value ..... 32 |
| 6 | Flash mode ..... 28 | 17 | Image mode ..... 84 |
| 7 | Internal memory indicator ..... 21 | 18 | Color options ..... 91 |
| 8 | Battery level indicator ..... 20 | 19 | White balance mode ..... 86 |
| 9 | ISO sensitivity ..... 29, 91 | 20 | Best shot selector (BSS) ..... 90 |
| 10 | Electronic vibration reduction icon ..... 29, 92 | 21 | Continuous shooting mode ..... 88 |
| 11 | Self-timer indicator ..... 30 | | |

* Differs according to the current shooting mode. Refer to the sections on each mode for details.

## Playback




| | | | |
|---|---|---|---|
| 1 | Date of recording ..... 16 | 9 | Movie playback indicator ..... 64 |
| 2 | Time of recording ..... 16 | 10 | Voice memo icon ..... 53 |
| 3 | Internal memory indicator ..... 26 | 11 | **a** Compensated image ..... 49<br>**b** Electronic VR not available ..... 49, 92 |
| 4 | Battery level indicator ..... 20 | 12 | Image mode ..... 84 |
| 5 | File number and type ..... 115 | 13 | Small picture ..... 51 |
| 6 | Volume indicator ..... 53, 64 | 14 | Protect icon ..... 98 |
| 7 | Current frame number/total number of frames ..... 26<br>Movie length ..... 64 | 15 | Print-order icon ..... 81 |
| 8 | D-Lighting icon ..... 48 | 16 | Transfer icon ..... 74, 98 |
| | | 17 | Movie indicator ..... 64 |

## The ▶ (shooting/playback) Button




Press ▶ once in shooting mode to enter full-frame playback; press again to switch back to shooting mode. Pressing the shutter-release button halfway in playback mode (📖 26) will also activate shooting mode.

If the camera is turned off, hold down ▶ to turn the camera on in playback mode (📖 27).

## The MODE (mode) Button




Press MODE during shooting to display the shooting-mode selection menu, or during playback to display the playback-mode selection menu. Use the multi selector and press the OK button to choose the desired mode.

- Press ▶ to switch between the mode-selection menus for shooting mode and playback mode.

### Shooting-mode Selection Menu




### Playback-mode Selection Menu



## The MENU Button

Press MENU to display the menu for the selected mode.




| | | | |
|---|---|---|---|
| Shooting menu | 83 | Playback menu | 94 |
| High-sensitivity menu | 83 | Calendar menu | 57 |
| Scene menu | 34 | List by date menu | 57 |
| One-touch portrait menu | 44 | Print menu | 78 |
| Movie menu | 59 | | |

- To display the setup menu for shooting or playback mode, choose in the shooting-mode or playback-mode selection menu and then press OK (8, 100).

### Navigating the Menus

The multi selector is used for menu navigation.



## Making a Selection




Press MENU button to display menus.

Use multi selector to select menu.

Some menus contain multiple pages. Press multi selector up or down to display the additional pages.

Shows multiple pages in current menu




Shows more options in current menu




Press OK button or multi selector to right to display options.




Highlight option.




Press OK button or multi selector to right to make selection.

- The selection for some options is made from a sub-menu. Press OK button or multi selector to right the sub-menu.
- To return to the previous menu without making a selection, press the multi selector to the left.
- To exit the menu, press MENU button.

## Turning On and Off the Camera

To turn on the camera, press the power switch. The power-on lamp (green) will light and the monitor will turn on. To turn off the camera, press the power switch again.

If the camera is turned off, hold down ▶ to turn the camera on in playback mode (26).




## Help Displays

Press ? (**T**) to view a description of the currently selected menu option.










- To return to the original menu, press ? (**T**) again.
- Press MENU to return to shooting or playback mode.

# Charging the Battery

The camera uses a Rechargeable Li-ion Battery EN-EL10 (supplied).

Charge the battery with the Battery Charger MH-63 (supplied) before first use or when the battery is running low.



## 1 Connect the power cable

Connect the power cable to the battery charger ① and insert the wall plug into a power outlet ②. The CHARGE lamp will light to show that the charger is on ③.




## 2 Charge the battery

Insert the battery into the battery charger.




The CHARGE lamp starts blinking when battery is inserted. Charging is complete when lamp stops blinking.




About 100 minutes are required to charge a fully depleted battery.

| CHARGE lamp | Description |
|---|---|
| Blinks | Battery charging. |
| On | Battery fully charged. |
| Flickers | Battery error. If ambient temperature is not 5 to 35 °C (41 to 95 °F), wait until temperature is in this range before charging. Otherwise unplug charger and remove battery immediately and take both devices to retailer or Nikon-authorized service representative. |



## 3 Unplug the charger

Remove the battery and unplug the charger when charging is complete.

### Note on the Battery Charger

Be sure to read and follow the warnings for the battery charger on pages iii and iv before using the battery charger.

The supplied battery charger MH-63 is for use only with a Rechargeable Li-ion Battery EN-EL10. Do not use with incompatible batteries.

### Note on the Battery

Be sure to read and follow the warnings for the battery on page iii and the section, "Caring for the Camera" (116), before using the battery.

### Alternative Power Resources

To power the camera continuously for extended periods, use an AC Adapter EH-62D (available separately from Nikon) (114). ***Do not, under any circumstances, use another make or model of AC adapter***. Failure to observe this precaution could result in overheating or in damage to the camera.

# Inserting the Battery

Insert a Rechargeable Li-ion Battery EN-EL10 (supplied) that has been fully charged, using the Battery Charger MH-63 (supplied), into your camera.



**1** Open the battery-chamber/memory card slot cover.



**2** Insert the battery.

Confirm that the positive (+) and negative (-) terminals are oriented correctly as described on the label at the entrance of the battery chamber, and insert the battery. The orange battery latch is pushed aside as the battery is inserted.

The battery is fully inserted when the battery latch clicks back into place.




### ☑ Inserting the Battery

**Inserting the battery upside down or backwards could damage the camera.** Be sure to check the battery is in the correct orientation.



**3** Close the battery-chamber/memory card slot cover.



## Removing the Battery

Turn the camera off before removing the battery. To eject the battery, open the battery-chamber/memory card slot cover and slide the orange battery latch in the direction shown ①. The battery can then be removed by hand ②.




- Note that the battery may become hot during use; observe due caution when removing the battery.

# Setting Display Language, Date, and Time

A language-selection dialog is displayed the first time the camera is turned on.



## 1 Press the power switch to turn on the camera.

The power-on lamp will light and the monitor will turn on.




## 2 Use the multi selector to choose the desired language and press ⓞ.

For information on using the multi selector, see "Making a Selection" (10).

## 3 Choose [Yes] and press ⓞ.

If [No] is selected, the date and time will not be set.




## 4 Press ⓞ.

The home time zone menu is displayed.




### Daylight Saving Time

If daylight saving time is in effect, turn on [Daylight saving] in the time zone menu and set the date.

1. Before pressing ⓞ, press the multi selector down to choose [Daylight saving].
2. Press ⓞ to enable daylight saving time (✔). Pressing ⓞ toggles the daylight saving time option on and off.
3. Press the multi selector up, and then press ⓞ to proceed to step 5.

When daylight saving time ends, turn [Daylight saving] off from the date menu (103) in the setup menu. The camera's clock is automatically set back one hour.

**5** Select your home time zone (📖 105) and press ⓞⓚ.

The date menu is displayed.




**6** Edit the day ([D]) (order of the day, month, and year may differ in some areas) and press ⓞⓚ.




**7** Edit the month ([M]) and press ⓞⓚ.




**8** Repeat steps 6 and 7 to edit the year ([Y]), hour, and minutes. Press ⓞⓚ after setting each item.

The row for setting the order in which the date is displayed will blink.




**9** Choose the order in which the day, month, and year are displayed and press ⓞⓚ.

The settings are applied and monitor display returns to shooting mode.



# Inserting Memory Cards

Pictures are stored in the camera's internal memory (20 MB) or on removable Secure Digital (SD) memory cards (available separately) (114).

*If a memory card is inserted in the camera, pictures are automatically stored on the memory card and pictures recorded to the memory card can be played back, deleted, or transferred. Remove the memory card to store pictures in the internal memory, or play back, delete, or transfer pictures from the internal memory.*



## 1 Turn the camera off and open the battery-chamber/memory card slot cover.




If the power-on lamp is lit, press the power switch to turn off the camera.

*Make sure that the camera is off* (power-on lamp is off) before inserting or removing the memory card.

## 2 Insert the memory card.




Slide the memory card in until it clicks into place.

Close the battery-chamber/memory card slot cover.

### Inserting Memory Cards



**Inserting the memory card upside down or backwards could damage the camera or the memory card.** Make sure that the memory card is correctly oriented.

## Removing Memory Cards

Before removing memory cards, ***turn the camera off*** and confirm that the power-on lamp is off. Open the battery-chamber/memory card slot cover and press the card in ① to partially eject the card ②. The card can then be removed by hand.






### Formatting Memory Cards

If the message at right is displayed, the memory card must be formatted before use. Note that ***formatting permanently deletes all pictures*** and other data on the memory card. Be sure to make copies of any pictures you wish to keep before formatting the memory card.




Use the multi selector to choose [Format] and press OK. The screen shown at right will be displayed. To start formatting, choose [Format] again and press OK.

- ***Do not turn the camera off or remove the battery or memory card until formatting is complete.***
- The first time you insert the memory cards used in other devices into the COOLPIX S200, be sure to format them (110).

### The Write Protect Switch

SD memory cards are equipped with a write protect switch. Pictures cannot be recorded or deleted and the memory card cannot be formatted when this switch is in the "lock" position. Unlock by sliding the switch to the "write" position.




### Memory Cards

- Use only Secure Digital memory cards.
- Do not perform the following during formatting, while data are being written to or deleted from the memory card, or during data transfer to a computer. Failure to observe this precaution could result in the loss of data or in damage to the camera or memory card.
  - Eject the memory card
  - Remove the battery
  - Turn off the camera
  - Disconnect the AC adapter
- Do not disassemble or modify.
- Do not drop, bend, or expose to water or strong physical shocks.
- Do not touch the metal terminals with your fingers or metal objects.
- Do not affix labels or stickers to the memory card.
- Do not leave in direct sunlight, closed vehicles, or areas exposed to high temperatures.
- Do not expose to humidity or to corrosive gases.

# Step 1 Turn the Camera On and Select (Auto) Mode

This section describes how to take pictures in (auto) mode, an automatic, "point-and-shoot" mode recommended for first-time users of digital cameras.

**1** Press the power switch to turn the camera on.

The power-on lamp will light and the monitor will turn on.

Proceed to step 4 when is displayed.




**2** Press MODE.




**3** Use the multi selector to choose and press OK.

The camera enters (auto) mode.

**4** Check the battery level and number of exposures remaining.

Battery level

| Monitor | Description |
|---|---|
| NO INDICATOR | Battery fully charged. |
| | Battery low; charge or replace the battery. |
| Warning! Battery exhausted. | Battery exhausted. Recharge or replace with a fully charged battery. |




Number of exposures remaining

The number of pictures that can be stored depends on the capacity of the memory or memory card and image mode setting.

## Indicators Displayed in (Auto) Mode






### Available Functions in (Auto) Mode

In (auto) mode, macro close-up mode (31) and exposure compensation (32) can be applied and pictures can be taken using the flash (28) and self-timer (30). Pressing MENU in (auto) mode displays the shooting menu. This menu allows you to specify the image mode (84), white balance setting (86), and to apply continuous shooting (88), BSS (90), ISO sensitivity (91), and color options (91) to suit shooting conditions or your own preferences.

### Auto Power off (Stand-by Mode)

If no operations are performed for about five seconds in shooting mode, the monitor will gradually dim to save power. Full brightness can be restored by pressing the shutter-release button or operating any of the controls next to the monitor. If no operations are performed for about a minute, the monitor will turn off altogether and the camera will enter stand-by mode, further reducing the drain on the battery (109). The camera will turn off automatically if no operations are performed for another three minutes.

# Step 2 Frame a Picture

## 1 Ready the camera.

Hold the camera steadily in both hands, keeping your fingers and other objects away from the lens, flash, and self-timer lamp. When taking pictures in portrait orientation with the camera rotated 90 °, hold the camera with the flash uppermost.




## 2 Frame the picture.

Position the main subject near the center of the monitor.



## Using the Zoom

Use the zoom buttons to activate optical zoom. Press **W** to zoom out, increasing the area visible in the frame, or **T** to zoom in so that the subject fills a larger area of the frame.




When the camera is zoomed in to the maximum magnification (3×), holding down **T** triggers digital zoom. The subject is magnified up to 4×, for a total magnification of 12×.

**A monitor indicator shows the current zoom ratio.**




Zoom indicator displayed when the zoom buttons are pressed.

Optical zoom (up to 3×)

Zoom indicator turns yellow when digital zoom is in effect.



**Digital Zoom**

Unlike optical zoom, data from the camera's image sensor are processed digitally with digital zoom. Details visible at maximum optical zoom are simply enlarged, producing a slightly "grainy" image.

## 1 Focus

Press the shutter-release button halfway to set focus and exposure. If the camera is able to focus on the subject in the focus area at the center of the frame, the focus (AF●) indicator and focus area will be displayed in green. If they blink red, the camera was unable to focus. Change the composition and try again. The focus area is not displayed when digital zoom is in effect.




## 2 Take the picture

Press the shutter release button the rest of the way down to take the picture. Note that the flash may fire if the subject is poorly lit.

### Shutter-Release Button

The camera features a two-stage shutter-release button. To set focus and exposure, press the shutter-release button halfway, stopping when you feel resistance. Focus and exposure lock while the shutter-release button is held in this position. To release the shutter and take a picture, press the shutter-release button the rest of the way down. Do not use force when pressing the shutter-release button, as this may result in camera shake and blurred pictures.

Set focus and exposure

Take picture

### During Recording

While pictures are being recorded, the ⌛ (wait) icon will be displayed, and the IN icon or the [ ] icon (when memory card is inserted) will blink. Do not turn the camera off, open the battery-chamber/memory card slot cover, or remove or disconnect the power source while these icons are displayed. Cutting power or removing the memory card in these circumstances could result in loss of data or in damage to the camera or card.

### Autofocus

Autofocus may not perform as expected in the following situations:

- Subject is very dark
- Objects of sharply differing brightness are included in the scene (e.g., the sun is behind the subject and is in deep shadow)
- No contrast between the subject and surroundings (e.g., when the subject is standing in front of a white wall, wearing a white shirt)
- Several objects are at different distances from the camera (e.g., the subject is inside a cage)
- Subject is moving rapidly

In the situations noted above, try pressing the shutter-release button halfway to refocus several times, or use focus lock below.

### Focus Lock

To focus on off-center subjects, use focus lock as described below.

**1** Position the subject in the center of the frame.

**2** Press the shutter-release button halfway to set focus and exposure.

- Confirm that the focus indicator (AF●) is green.

**3** Continue holding down the shutter-release button halfway and recompose the picture.

- Be sure that the distance between the camera and the subject does not change.

**4** Press the shutter-release button the rest of the way down.

## Full-Frame Playback

**Press ▶.**




The last picture taken will be displayed.

Use the multi selector to view additional pictures.

Pictures may be displayed briefly at low resolution while being read from the memory card or internal memory.

Press ▶ or the shutter-release button to switch to shooting mode.

When IN is displayed, pictures stored in the internal memory will be displayed. When memory card is inserted, IN is not displayed and pictures stored on the memory card will be displayed.

Internal memory indicator




## Deleting Pictures

**1** Press 🗑 to delete the picture currently displayed in the monitor.




**2** Use the multi selector to select [Yes] and press ⓞ.

To exit without deleting the picture, choose [No] and press ⓞ.






## Full-Frame Playback Mode

The following options are available in full-frame playback mode.

| Option | Press | Description | 📖 |
|---|---|---|---|
| Playback zoom | **T** (🔍) | Press **T** (🔍) to enlarge view of picture currently displayed in monitor up to about 10×. | 46 |
| View thumbnails | **W** (▦) | Press **W** (▦) to display four, nine, or, 16 picture thumbnails. | 45 |
| Electronic VR | Ⓚ ((✋)) | Press Ⓚ while displaying a picture to compensate a blurred image. | 49 |
| View playback menu | MENU | Press MENU button to view playback menu. | 94 |
| View playback mode menu | MODE | Press MODE button to view playback mode menu. | 8 |
| Switch to shooting mode | ▶ ↓ | Press ▶ or the shutter-release button to switch to the shooting mode selected in the shooting-mode selection menu. | 26 |

**Quick Playback Zoom**

Pressing **T** (🔍) during full-frame playback zooms the current picture in 3×, with the center of the picture displayed in the monitor (Quick Playback Zoom) (📖 46).
Press Ⓚ to return to full-frame playback.




## Viewing Pictures

- Except in 🎙 mode, pressing the power switch to turn the camera on or pressing the ▶ button to switch from playback to shooting restores the last shooting mode selected, while pressing ▶ to initiate playback automatically selects ▶ (playback) mode. Switching to shooting mode from 🎙▶ (voice playback) selects 🎙 (voice recording); pressing ▶ to initiate playback in 🎙 (voice recording) mode automatically selects 🎙▶ (voice playback).
- Pictures stored in the internal memory can only be viewed if no memory card is inserted.

## Deleting the Last Shot

To delete the most recent picture, press the 🗑 button while the camera is in shooting mode. A confirmation dialog will be displayed; highlight [Yes] and press Ⓚ to delete the last shot taken.



# Using the Flash

The flash has a range of 0.3–4.6 m (11.9 in.–15 ft. 1.1 in.) when the camera is zoomed out all the way. With maximum optical zoom applied, the range is 0.3–2.5 m (11.9 in.–8 ft. 2.4 in.) (when [ISO sensitivity] is set to [Auto]). The following flash modes are available:

| | |
|---|---|
| AUTO | **Auto (default for 📷 (auto) mode)** |
| | Flash fires automatically when lighting is poor. |
| ◉ | **Auto with red-eye reduction** |
| | Reduces "red-eye" in portraits (29). |
| ⊘ | **Off** |
| | Flash will not fire even when lighting is poor. |
| ⚡ | **Fill flash** |
| | Flash fires when a picture is taken. Use to "fill-in" (illuminate) shadows and back-lit subjects. |
| SLOW | **Slow sync** |
| | Flash illuminates main subject; slow shutter speeds are used to capture background at night or under dim light. |



## 1 Press ⚡ (flash mode).

The flash menu is displayed.

## 2 Use the multi selector to choose the desired flash mode and press ⓞ.

The icon for the selected flash mode is displayed at the top of the monitor.

When AUTO (auto) is applied, AUTO is only displayed for five seconds.

The flash mode applied in 📷 (auto) mode and high-sensitivity shooting mode is stored in the camera's memory even after the camera is turned off.

If a setting is not applied by pressing ⓞ within five seconds, the selection will be cancelled.






### The (Off) Indicator

Note the following when lighting is poor and the flash is off ().

- Place the camera on a flat, level surface or use a tripod (recommended).
- The ISO is displayed when the camera automatically increases sensitivity to minimize blur caused by slow shutter speed (6). Pictures taken when ISO is displayed may be slightly mottled.

### Note on Using the Flash

Light from the flash reflected from particles of dust or other matter in the air may appear in pictures as bright specks. If this occurs, turn the flash off and try again.

### The Flash Lamp

The flash lamp indicates flash status when the shutter-release button is pressed halfway.

- **On**: Flash will fire when picture is taken.
- **Blinks**: Flash charging. Wait a few seconds and try again.
- **Off**: Flash will not fire when picture is taken.



### Advanced Red-Eye Reduction

The COOLPIX S200 is equipped with an advanced red-eye reduction system. Pre-flashes are fired several times at low intensity before the main flash to reduce "red-eye." If the camera detects "red-eye" after a picture is taken, Nikon's own In-Camera Red-Eye Fix processes the image as it is recorded. Therefore, there is a slight delay before the shutter-release button operates normally to take another picture.

- Not recommended for when shutter-release timing is essential.
- Red-eye reduction may not always produce the desired results.
- In some rare cases, other portions of pictures may be affected.

Use flash modes other than auto with red-eye reduction in above cases.

### Electronic VR

When flash mode is set to  or , Electronic VR (92) will be enabled according to shooting conditions and may be applied to blurred pictures when they are recorded ( is displayed in the monitor when shooting).

Electronic VR can be set to [Off] in the [Electronic VR] option of the shooting menu (92).

# Taking Pictures with the Self-Timer

The camera is equipped with a ten-second and three-second timer for self-portraits. When using the self-timer, use of a tripod is recommended.

## 1 Press ⏲ (self-timer).

The self-timer menu is displayed.

## 2 Use the multi selector to choose [10s] or [3s] and press ⓞ.

[10s] (ten seconds): suited for important occasions (such as weddings)

[3s] (three seconds): suited for preventing camera shake

The mode selected for self-timer is displayed.




If a setting is not applied by pressing ⓞ within five seconds, the selection will be cancelled.

## 3 Frame the picture and press the shutter-release button halfway.

Focus and exposure will be set.




## 4 Press the shutter-release button the rest of the way down.

The self-timer starts and the self-timer lamp will blink. The lamp stops blinking one second before the photograph is taken and remains lit until the shutter is released.

The number of seconds remaining before the shutter is released is displayed in the monitor.

To stop the timer before a picture is taken, press the shutter-release button again.






# Macro Close-up Mode

Macro close-up mode is used for taking pictures of objects as close as 10 cm (3.9 in.). Note that the flash may be unable to light entire subject at distances of less than 30 cm (11.8 in.).

## 1 Press (macro close-up mode).

The macro close-up menu is displayed.

## 2 Use the multi selector to choose [ON] and press OK.

The macro close-up mode icon ( ) is displayed.

When [OFF] is selected, OFF is only displayed for five seconds.

The monitor will return to the normal display for the current mode if the setting is not applied by pressing OK within five seconds.




## 3 Press T or W to frame the picture.

Camera can focus at distance of 10 cm (3.9 in.), if zoom is adjusted until icon turns green.




## 4 Focus and shoot.

The macro close-up mode applied in (auto) mode or high-sensitivity shooting mode is stored in the camera's memory even after the camera is turned off.



### Macro Close-up Mode

In macro close-up mode, the camera focuses continuously, even when the shutter-release button is not pressed halfway to lock focus.

# Exposure Compensation

Exposure compensation is used to alter exposure from the value suggested by the camera to make pictures brighter or darker.

**1** Press the multi selector ⊠ (exposure compensation).

- The exposure compensation menu is displayed.

**2** Use the multi selector to adjust exposure.

- When the picture is too dark: adjust the exposure compensation to "+" side.
- When the picture is too bright: adjust the exposure compensation to "-" side.
- Exposure compensation can be set to values between -2.0 and +2.0 EV.

**3** Press ⓞⓚ.

- The ⊠ icon and compensation value are displayed in the monitor.
- The monitor will return to the normal display for the current mode if the setting is not applied by pressing ⓞⓚ within five seconds.
- The exposure compensation applied in 📷 mode or high-sensitivity shooting mode is stored in the camera's memory even after the camera is turned off.



# Shooting in High-sensitivity Shooting Mode

In high-sensitivity shooting mode, sensitivity is increased with shooting under low lighting to reduce blurring caused by camera shake or subject movement, allowing you to capture the atmosphere of the scene. ISO sensitivity will be automatically increased to a maximum of 1000 depending upon the brightness of the subject.

**1** Press MODE in shooting mode. Use multi selector to select HI ISO and press OK.




**2** Frame the subject and take the picture.




### Notes on High-sensitivity Shooting Mode

- This mode reduces effects of camera shake even for shooting under low lighting; however, when shooting without the flash, use of a tripod is recommended.
- Pictures taken in this mode may become somewhat grainy.
- Focus may not be precisely fixed in extremely dark places.

### High-sensitivity Shooting and Anti-shake Modes

Both high-sensitivity shooting mode and anti-shake mode (42) reduce blurring caused by camera shake and subject movement. However, high-sensitivity shooting mode is suited for shooting under low lighting. In some circumstances, disabling the flash may make it even easier to capture the true essence of the scene.

In high-sensitivity shooting mode, pressing MENU displays the high-sensitivity menu. The items available from this menu are the same as those available in the (auto) mode shooting menu (83), except that [ISO sensitivity] and [Electronic VR] are not available in the high-sensitivity menu. Just as with (auto) mode, the flash, self-timer, macro close-up mode, and exposure compensation are available.

In anti-shake mode, Electronic VR (92) and BSS (90) are enabled to reduce blurring caused by camera shake or subject movement, and the flash is disabled. Sensitivity is set higher and shutter speed is faster than with (auto) mode under the same lighting conditions. This mode is suited to shooting under natural light when the camera is zoomed in.

# Shooting in Scene Modes

The camera offers a choice of 15 "scene" options. Camera settings are automatically optimized for the selected subject type.

| | | |
|---|---|---|
| Portrait | Beach/snow | Museum |
| Landscape | Sunset | Fireworks show |
| Sports | Dusk/dawn | Copy |
| Night portrait | Night landscape | Back light |
| Party/indoor | Close up | Panorama assist |



**1** Enter scene mode by pressing MODE in shooting mode, selecting SCENE (use the multi selector), and then pressing OK.




**2** Press MENU to display the scene menu screen, and choose the desired scene mode and press OK.




**3** Frame the subject and take the picture.




### Image Mode

[Image mode] (84) can be set in the scene menu. Changes made to these settings apply to all shooting modes.



## Features

### Portrait

Use this mode for portraits in which the main subject stands out clearly. Portrait subjects exhibit smooth, natural-looking skin tones.
- Camera focuses on subject in the center of the monitor.

| | | | | | | | |
|---|---|---|---|---|---|---|---|
| ϟ | ϟ◉* | ⏲ | Off* | 🌷 | Off | ± | 0* |

* Other settings can be selected.

### Landscape

Use this mode for vivid landscapes and cityscapes.
- Camera focuses at infinity. The focus indicator (📖 24) always glows green when the shutter-release button is pressed halfway. Note, however, that objects in the foreground may not always be in focus.

| | | | | | | | |
|---|---|---|---|---|---|---|---|
| ϟ | ⊛ | ⏲ | Off* | 🌷 | Off | ± | 0* |

* Other settings can be selected.

### Sports

Use this mode for dynamic action shots that freeze the action in a single shot and record motion in a series of pictures.
- While the shutter-release button is pressed halfway, the camera focuses continuously until focus is acquired and locked.
- While the shutter-release button is held down, pictures are taken at rate of about 1.3 frames per second (fps) ([▯ Normal (3072)]).

| | | | | | | | |
|---|---|---|---|---|---|---|---|
| ϟ | ⊛ | ⏲ | Off | 🌷 | Off | ± | 0* |

* Other settings can be selected.

Depending on the scene selected, restrictions may apply to flash mode (ϟ; 📖 28), the self-timer (⏲; 📖 30), macro close-up (🌷; 📖 31), or exposure compensation (±; 📖 32). These restrictions are noted on the pages that follow.

### Night Portrait

Use this mode to achieve a natural balance between the main subject and background lighting in portraits taken at night.

| | | | | | | | |
|---|---|---|---|---|---|---|---|
| | [1] | | Off[2] | | Off | | 0[2] |

1 Fill flash with slow sync and red-eye reduction.
2 Other settings can be selected.

### Party/indoor

Captures the effects of candlelight and other indoor background lighting.
- Camera focuses on subject in center of frame.
- Hold the camera steadily to prevent camera shake under low lighting.

| | | | | | | | |
|---|---|---|---|---|---|---|---|
| | [1] | | Off[2] | | Off | | 0[2] |

1 Fill flash with slow sync and red-eye reduction. Other settings can be selected.
2 Other settings can be selected.

### Beach/snow

Captures the brightness of such subjects as snowfields, beaches, or sunlit expanses of water.
- Camera focuses on subject in center of frame.

| | | | | | | | |
|---|---|---|---|---|---|---|---|
| | AUTO* | | Off* | | Off | | 0* |

* Other settings can be selected.

Scene Mode

: For those scene modes with , use of a tripod is recommended.
: For those scene modes with , noise reduction may be automatically applied as pictures taken are recorded; results in increased recording times.

### Sunset

Preserves the deep hues seen in sunsets and sunrises.
- Camera focuses on subject in center of frame.
- Hold the camera steadily to prevent camera shake under low lighting.

| | | | | | | | |
|---|---|---|---|---|---|---|---|
| ϟ | ⊛* | ⏲ | Off* | ❀ | Off | ± | 0* |

* Other settings can be selected.

### Dusk/dawn

Preserves the colors seen in the weak natural light before sunrise or after sunset.
- Camera focuses at infinity. When the shutter-release button is pressed halfway, the focus indicator (24) always lights; however, focus may not be set for near subjects, while the camera focuses at infinity.

| | | | | | | | |
|---|---|---|---|---|---|---|---|
| ϟ | ⊛ | ⏲ | Off* | ❀ | Off | ± | 0* |

* Other settings can be selected.

### Night landscape

Slow shutter speeds are used to produce stunning night landscapes.
- Camera focuses at infinity. When the shutter-release button is pressed halfway, the focus indicator (24) always lights; however, focus may not be set for near subjects, while the camera focuses at infinity.

| | | | | | | | |
|---|---|---|---|---|---|---|---|
| ϟ | ⊛ | ⏲ | Off* | ❀ | Off | ± | 0* |

* Other settings can be selected.

### Close up

Photograph flowers, insects, and other small objects at close range.

- The camera can focus at distances as close as 10 cm (3.9 in.).
- The camera can be zoomed when the zoom indicator is between [W] and △ positions.
- While the shutter-release button is pressed halfway, the camera focuses continuously until focus is acquired and locked.
- Macro close-up shooting (31) can be used for this option.
- Hold the camera steadily to prevent camera shake.

| | | | | | | | |
|---|---|---|---|---|---|---|---|
| ϟ | ϟAUTO* | ⏲ | Off* | 🌷 | On | ± | 0* |

* Other settings can be selected.



### Museum

Use indoors where flash photography is prohibited (for example, in museums and art galleries) or in other settings in which you do not want to use the flash.

- Camera focuses on subject in center of frame.
- BSS (90) turns on automatically.
- Hold the camera steadily to prevent camera shake.

| | | | | | | | |
|---|---|---|---|---|---|---|---|
| ϟ | ⊗ | ⏲ | Off* | 🌷 | Off* | ± | 0* |

* Other settings can be selected.

### Fireworks show

Slow shutter speeds are used to capture the expanding burst of light from a firework.

- Camera focuses at infinity. When the shutter-release button is pressed halfway, the focus indicator (24) always lights; however, focus may not be set for near subjects, while the camera focuses at infinity.

| | | | | | | | |
|---|---|---|---|---|---|---|---|
| ϟ | ⊗ | ⏲ | Off | 🌷 | Off | ± | 0 |

: For those scene modes with , use of a tripod is recommended.

### Copy

Provides clear pictures of text or drawings on a white board or in print.

- Camera focuses on subject in center of frame.
- Use macro close-up mode (31) to focus at short ranges.
- Colored text and drawings may not show up well.




| | | | | | | | |
|---|---|---|---|---|---|---|---|
| ϟ | ⊛* | ⏲ | Off* | | Off* | ± | 0* |

* Other settings can be selected.

### Back light

Use when light is coming from behind your subject, throwing features or details into shadow. The flash fires automatically to "fill in" (illuminate) shadows.

- Camera focuses on subject in center of frame.

| | | | | | | | |
|---|---|---|---|---|---|---|---|
| ϟ | ϟ | ⏲ | Off* | | Off | ± | 0* |

* Other settings can be selected.

## Panorama assist

Use when taking a series of pictures that will later be joined to form a single panorama using PictureProject.

| | | | | | | | |
|---|---|---|---|---|---|---|---|
| ϟ | ϟ* | | Off* | | Off* | | 0* |

* Other settings can be selected.



### Taking Pictures for a Panorama

The camera focuses on the subject in the center of the frame. Use a tripod for best results.

**1** Use the multi selector to choose [Panorama assist] in the scene menu and press OK.

The yellow panorama direction icon (▷) is displayed to show the direction in which pictures will be joined.

**2** Use the multi selector to choose the direction and press OK.

Select how pictures will be joined together in the completed panorama; right (▷), left (◁), up (△), or down (▽). The panorama direction icon (▷) is displayed to the direction pressed, and changes to white when OK is pressed. Apply flash (28), self-timer (30), macro close-up mode (31), and exposure compensation (32) settings with this step, if necessary. Press OK to reselect the direction.



**3** Take the first picture.

The first picture is displayed in the first third of the monitor.

## 4 Take the second picture.

Compose the next picture so that it overlaps the first picture.

Repeat until you have taken the necessary number of pictures to complete the scene.

## 5 Press ⓞ when shooting is completed.

The camera returns to step 2.






### Panorama Assist

Flash mode (28), self-timer (30), macro close-up (31), and exposure compensation (32) settings cannot be adjusted after the first picture is taken. Pictures cannot be deleted, nor can zoom or image-mode setting (84) be adjusted until the series is finalized.

The panorama series is terminated if the camera enters standby mode with the auto off function (109) during shooting. Setting the time allowed to elapse before the camera enters standby mode to a longer setting is recommended.

### Exposure Lock

AE-L (white) is displayed to indicate that white balance and exposure have been locked at the values set with the first shot. All pictures taken in a panorama series have the same exposure and white-balance settings.



# Shooting in Anti-shake Mode

In anti-shake mode, Electronic VR (📖 92) and BSS (📖 90) are enabled. In addition, ISO sensitivity is automatically raised to 1000 depending upon the brightness of the subject and shutter speed is faster than with 📷 (auto) mode, under the same lighting conditions, to reduce blurring caused by camera shake or subject movement. The flash is disabled. This mode is most effective when shooting under natural light. Combine it with telephoto zoom when you are forced to shoot from a distance in order to capture a fleeting expression on a portrait subject or to photograph an animal without frightening it off.

## 1 Press ((✋)).

The camera enters anti-shake mode. Press again to return to the shooting mode selected in the shooting-mode selection menu.




## 2 Frame the subject and take the picture.

Camera focuses on subject in center of frame.

While the shutter-release button is held down, camera takes shots to a maximum of ten, they are compared and sharpest picture (picture with highest level of detail) is saved.




### Notes on Anti-shake Mode

- Shutter speed is limited to a certain value for dark subjects.
- Use of the high-sensitivity shooting mode (📖 33) is recommended for shooting subjects under low lighting.
- Pictures taken in this mode may become somewhat grainy.
- Date imprint (📖 107) is not available in anti-shake mode.
- Anti-shake mode is not available in panorama assist mode (📖 40).

### Anti-shake Mode Settings

Electronic VR (📖 92) and BSS (📖 90) are enabled; the flash is disabled. Macro close-up mode and exposure compensation are available; the self-timer is not available.

### Image Mode in Anti-shake Mode

When MENU is pressed in anti-shake mode, adjustment of image mode (📖 84) settings is enabled. Changes made to these settings apply to all shooting modes.

# Taking Pictures in the One-Touch Portrait Mode

For portrait shots, select in the shooting mode menu (8).

The following features are automatically activated:

- Portrait: The portrait subject stands out clearly.
- Face-priority AF: The camera automatically detects and focuses on faces.
- Advanced red-eye reduction: Reduces "red-eye" caused by the flash (29). Other flash modes can be selected.
  Macro close-up is not available in one-touch portrait mode.

## 1 Press MODE in shooting mode. Use multi selector to select and press OK.

A yellow guide is displayed.



## 2 Frame a picture using the guide.



When the camera detects a face, the guide is displayed with a double yellow border.

When the camera detects more than one face, the closest face is framed by a double border and the rest by a single border. The camera focuses on the face framed by the double border and adjusts exposure accordingly. If the camera loses its ability to detect a face (for example, because the subject has looked away from the camera), borders are no longer displayed and monitor display returns to that shown in step 1.

## 3 Press the shutter-release button halfway.

Focus and exposure are set, and the double border glows green.



## 4 Press the shutter-release button the rest of the way down to take a picture.

# The One-Touch Portrait Menu

Press MENU in one-touch portrait mode to display the one-touch portrait menu. In addition to image mode, portrait effects (reducing vividness of skin tones, softening overall image) can be set.

| | |
|---|---|
| | **Image mode** |
| | Choose an image size and quality (84). |
| | **Portrait effect** |
| | Choose from [Normal], [Brighter] (reduces vividness of skin tones), and [Softer] (soft effect). |

- To exit the one-touch portrait menu, press MENU or shutter-release button.



### Face-Priority AF

- The camera's ability to detect faces depends on a variety of factors, including whether or not the subject is facing the camera.
- The camera focuses continuously until a face is detected.
- If the yellow double border blinks when the shutter-release button is pressed halfway, the camera was unable to focus. Release the button and try again.
- If no face is recognized when the shutter-release button is pressed halfway, the camera focuses on the center of the frame.
- The camera may be unable to detect faces in the following situations:
  - When faces are partially hidden by sunglasses or other obstructions
  - When faces take up too much or too little of the frame

### Settings for One-Touch Portrait Mode

- Flash: Changeable
- Self-timer: Available
- Macro close-up: Off
- Exposure compensation: Available

# Viewing Multiple Pictures: Thumbnail Playback

Press **W** (▪) in full-frame playback (📖 26) to display pictures in "contact sheets" of thumbnail images. The following operations can be performed while thumbnails are displayed:




| To | Use | Description | 📖 |
|---|---|---|---|
| Choose pictures | | Use the multi selector to choose pictures. | 9 |
| Change number of pictures displayed |  | When **W** (▪) is pressed, display picture thumbnails in the following order: 4 → 9 → 16 When **T** (🔍) is pressed, the number of thumbnails changes reversely. | – |
| Cancel thumbnail playback | ⊛ | Press ⊛ to cancel thumbnail playback and return to full-screen playback. | 26 |
| Delete highlighted picture | 🗑 | Confirmation dialog displayed. Press multi selector up or down to highlight option. Select Yes to delete picture. | 26 |
| Display menus | MENU | Press MENU button to display playback menus. | 94 |
| Display mode menu | MODE | Press MODE button to display playback mode menu. | 8 |
| Switch to shooting mode |  | Press ▶ or the shutter-release button to return to the last shooting mode selected. | 26 |

### 4-/9-picture Thumbnail Playback Mode Display

When protected pictures and pictures selected for transfer are displayed in 9-picture thumbnail playback mode, the icons shown at right are displayed with them. Movies are displayed as film frames. Icons are not displayed with protected pictures or pictures selected for transfer in 16-picture thumbnail playback modes.



# Taking a Closer Look: Playback Zoom

Pressing **T** (Q) during full-frame playback (26) zooms the current picture in 3×, with the center of the picture displayed in the monitor (Quick Playback Zoom).

The guide at lower right shows which portion of the picture is enlarged. Change the portion of the picture displayed by pressing the multi selector.

Use the zoom buttons with quick playback zoom to enlarge pictures to the desired magnification ratio. While the image is zoomed in, the zoom ratio is displayed in the monitor. The following operations can be performed while pictures are zoomed in:







| To | Use | Description | |
|---|---|---|---|
| Zoom in | **T** (Q) | Zoom increases each time **T** (Q) is pressed, to a maximum of 10×. | – |
| Zoom out | **W** (▪) | Zoom decreases each time **W** (▪) is pressed. When the magnification ratio reaches 1×, the display returns to full-frame playback. | – |
| View other areas of picture | | Press the multi selector to scroll to areas of the picture not visible in the monitor. | 9 |
| Switch to full-frame playback | OK | Press OK to cancel playback zoom and return to full-screen playback. | 26 |
| Crop picture | MENU | Press MENU to crop current picture to contain only the portion visible in the monitor. | 50 |
| Delete highlighted picture | 🗑 | Confirmation dialog displayed. Press multi selector up or down to highlight option. Select [Yes] to delete picture. | 26 |
| Display mode menu | MODE | Press MODE button to display playback mode menu. | 8 |
| Switch to shooting mode | ▶ | Press ▶ or the shutter-release button to return to the last shooting mode selected. | 26 |

# Editing Pictures

Use the COOLPIX S200 to edit pictures in-camera and store them as separate files (📖 115). The editing features described below are available.

| Editing function | Description |
|---|---|
| D-Lighting | Create a copy of the current picture with enhanced brightness and contrast, brightening dark portions of the picture. |
| Electronic VR | Compensates for slight hand movements that can blur pictures. |
| Crop | Enlarge the image or refine the composition and create a copy containing only the portion visible in the monitor. |
| Small picture | Create a small copy of pictures suitable for use on web pages or as e-mail attachments. |

### Picture Editing

- Pictures taken at an image mode setting of [16:9] (📖 84) cannot be edited except Electronic VR.
- The COOLPIX S200 editing functions may not be available for pictures taken with non-COOLPIX S200 digital cameras.
- If a copy created using the COOLPIX S200 is viewed on a different digital camera, the picture may not be displayed or may not be transferred to a computer.
- Editing functions are not available when there is not enough free space in the internal memory or on the memory card.

### Restrictions on Picture Editing

(✔: available, –: not available)

| | 2nd editing | | | |
|---|---|---|---|---|
| 1st editing | D-Lighting | Electronic VR | Crop | Small picture |
| D-Lighting | – | ✔ | ✔ | ✔ |
| Electronic VR | ✔ | – | ✔ | ✔ |
| Crop | – | – | – | – |
| Small picture | – | – | – | – |

- Pictures cannot be edited twice with the same editing function.
- The D-Lighting or Electronic VR should be done first while the restricted use of combination exists.

### Original Pictures and Edited

- Copies created with editing functions are not deleted if the original pictures are deleted. The original pictures are not deleted if copies created with editing functions are deleted.
- Edited copies are stored with the same recording date and time as the original.
- Edited copies have the same transfer marking (📖 98) as the original but are not marked for printing (📖 81) or protecting (📖 98).

## Enhancing Brightness and Contrast: D-Lighting

D-Lighting can be used to create copies with enhanced brightness and contrast, brightening dark portions of a picture. Enhanced copies are stored as separate files.

**1** Select the desired picture from full-frame (📖 26), or thumbnail (📖 45) playback and press MENU.

The playback menu is displayed.




**2** Highlight [D-Lighting] and press ⓞ.

The results of D-Lighting enhancement can be confirmed in the monitor.

**3** Use the multi selector to choose [OK] and press ⓞ.

A new copy with enhanced brightness and contrast is created.

To cancel D-Lighting, choose [Cancel] and press ⓞ.

D-Lighting copies can be recognized by the 🖼 icon displayed during playback.

## Compensating Blurred Images: Electronic VR

Vibration reduction is used to create a new image by compensating the blurred image. Created copies are stored as separated files.

**1** Choose the desired image in full-frame playback (26).




**2** Press ⊛ ((✋)) (electronic VR).




**3** Use the multi selector to choose [OK] and press ⊛.

Compensated image is created.

To cancel vibration reduction, choose [Cancel] and press ⊛.




For compensated images, the VR indicator is displayed in the monitor during playback.




### Note on Electronic VR

In addition to the restrictions described in "Restrictions on Picture Editing" (47), electronic VR cannot be used for the following pictures:

- Pictures taken with Multi-shot 16 (88), with slow shutter speeds, or with other cameras.
- Pictures with date imprint (107).
- Pictures with minor blur, or pictures that are badly blurred.
- Pictures that an VR icon or VR icon is displayed (92).

## Creating a Cropped Copy: Crop

This function is only available when MENU:✂ is displayed in the monitor with playback zoom (📖 46) enabled. Cropped copies are stored as separate files.

**1** Press **T** (🔍) to zoom in on the image.




**2** Refine copy composition.

Press **T** or **W** to adjust the zoom ratio.

Press the multi selector up, down, left, or right to scroll the picture until only the portion you want to copy is visible in the monitor.




**3** Press MENU.

The confirmation dialog will be displayed.




**4** Use the multi selector to choose [Yes] and press OK.

A new picture, containing only the portion visible in the monitor, is created.




Depending on the size of the original picture and the zoom ratio in effect at the time the copy was created, the camera will automatically select one of the following image-mode settings for cropped copies (unit: pixels).

- 5M 2,592 × 1,944
- 4M 2,272 × 1,704
- 3M 2,048 × 1,536
- 2M 1,600 × 1,200
- 1M 1,280 × 960
- PC 1,024 × 768
- TV 640 × 480
- 320 × 240
- 160 × 120

During playback, 320×240 and 160×120 copies are indicated by a gray border.

## Resizing Pictures: Small Picture

Create a small copy of the current picture. Small copies are stored as JPEG files with a compression ratio of 1:16. The following sizes are available.

| Option | Description |
|---|---|
| 640×480 | Suited to television playback. |
| 320×240 | Suited to display on web pages. |
| 160×120 | Suitable for e-mail attachments. |

**1** Select the desired picture from full-frame (26), or thumbnail (45) playback mode and press MENU.

The playback menu is displayed.




**2** Use the multi selector to choose [Small pic.] and press OK.




**3** Choose the desired copy size and press OK.

A confirmation dialog will be displayed.

To cancel, press MENU.




**4** Choose [Yes] and press OK.

A new, smaller copy is created.




During playback, copies are indicated by a gray border.

# Voice Memos: Recording and Playback

Use the camera's built-in microphone to record voice memos to pictures .

## Recording Voice Memos

**1** Select the desired picture from full-frame (📖 26), or thumbnail (📖 45) playback mode and press MENU.

The playback menu is displayed.




**2** Use the multi selector to choose [Voice memo] and press OK.

Display shows voice recording guides.







**3** Press OK.

A voice memo, up to 20 seconds in length, will be recorded while OK is pressed down.

Recording ends after about 20 seconds or when OK is released.

During recording, REC and [♪] blink in the monitor display.

Pictures for which voice memo exists are marked by [♪] (voice memo playback guide).

Press MENU button to return to playback mode.







### Voice Memos

- Do not touch the built-in microphone during recording.
- Voice memos are assigned the picture file name they are attached to with the three-letter extension ".WAV" (e.g., DSCN0015.WAV) (📖 115).
- If a voice memo already exists for the current picture, it must be deleted before a new voice memo can be recorded.
- The COOLPIX S200 may be not able to attach a voice memo to pictures recorded by other cameras.

## Playing Voice Memos

**1** Select the desired picture from full-frame (📖 26), or thumbnail (📖 45) playback mode and press MENU.




Pictures with voice memos can be recognized by the [♪] icons.

The playback menu is displayed.

**2** Use the multi selector to choose [Voice memo] and press OK.




Display shows voice playback guides.

**3** Press OK.




Play voice memo. Playback ends when the voice memo ends or OK is pressed again.

Use the zoom buttons to adjust playback volume. Press **W** to lower volume, or **T** to raise volume.

Press MENU button to return to playback mode.

## Deleting Voice Memos

To delete the voice memo for the current picture, press the 🗑 button. The dialog shown at right will be displayed; press the multi selector up or down to highlight an option and press the OK button to select.






- [No]: Exit without deleting the picture or voice memo.
- [[♪]]: Delete voice memo only.
- [Yes]: Delete both picture and voice memo.

# Viewing Pictures by Date

In calendar mode or list by date mode, pictures taken on a specified date can be displayed. When MENU is pressed, the calendar menu or the list by date menu is displayed, and all pictures taken on a specified date can be selected for deletion, printing, protection, and transfer.

## Selecting a Date in Calendar Mode

**1** Enter calendar mode by pressing MODE in playback mode, selecting (use the multi selector), and then pressing OK.

**2** Choose the desired date and press OK.

Dates for which pictures exist are underlined in yellow.

Press **W** to view previous month, press **T** to view following month.




The first picture for that date will be displayed full-frame.

Press **W** in full-frame playback to return to calendar mode.



## Selecting a Date in List by Date Mode

**1** Enter list by date mode by pressing MODE in playback mode, selecting DATE (use the multi selector), and then pressing OK.

Dates for which pictures exist will be listed.

**2** Choose the desired date and press OK.

Camera lists up to 29 dates. If pictures exist for more than 29 dates, all pictures recorded earlier than most recent 29 dates will be listed together as [Others].




The first picture for that date will be displayed full-frame.

Press **W** in full-frame playback to return to the date list.



## Using Calendar Mode and List by Date Mode

| To | Use | Description | |
|---|---|---|---|
| Select date | | Use the multi selector to select a date. | – |
| Select month (calendar mode only) |  | Press **W** to view previous month, press **T** to view following month. | – |
| Switch to full-frame playback | ⊛ | Press ⊛ to display the first picture taken on the selected date.<br>Press **W** to return to the calendar or list by date mode selected before viewing in full-frame playback. | 26 |
| Delete picture | 🗑 | Press 🗑 after selecting a date, and a confirmation dialog will be displayed. Choose [Yes] and press ⊛ to delete all pictures taken on the selected date. | 26 |
| View calendar or list by date menu | MENU | Press MENU to display the calendar or list by date menu. | 57 |
| View playback mode menu | MODE | Press MODE to display the playback-mode selection menu. | 8 |
| Switch to shooting mode | ▶<br> | Press ▶ or the shutter-release button to return to the last shooting mode selected. | 26 |



### Notes on Calendar Mode and List by Date Mode

- Up to 9,000 pictures can be registered in calendar mode or in list by date mode. If more pictures exist, "*" is displayed next to the number.
- Pictures taken with no date stamp are not listed in these modes.

## Calendar and List by Date Menus

Press MENU in either mode to display the following menus for only the pictures taken on the specified date.

| | |
|---|---|
| D-Lighting* | 48 |
| Print set | 81 |
| Slide show | 96 |
| Delete | 97 |
| Protect | 98 |
| Transfer marking | 98 |
| Small picture* | 51 |
| Voice memo* | 52 |

* During full-frame playback only

The procedure for selecting pictures in calendar or date list playback differs from that in full-frame playback as follows:

- In calendar or date list playback, the options apply to all pictures taken on the currently selected date.
- In full-frame playback, the options apply only to the picture currently displayed full frame, although other pictures taken on the same date can be selected.



### Print Set and Transfer Marking

When print or transfer marking already exists for pictures taken on dates other than that specified, a confirmation dialog [Save print marking for other dates?] or [Save transfer marking for other dates?] will be displayed. Select [Yes] to add the new print or transfer marking to the existing marking. Select [No] to remove the existing print or transfer marking and leave only the new marking.

# Recording Movies

To shoot movies, select shooting mode and follow the steps below. Except in the case of time-lapse and stop-motion movies, movies include sound recorded via the built-in microphone.

**1** **Enter movie mode by pressing MODE in shooting mode, selecting 🎥 (use the multi selector), and then pressing ⓞ.**




Exposure count display shows maximum total length of movie that can be recorded.

**2** **Press the shutter-release button all the way down to start recording.**




A progress bar at the bottom of the monitor shows the amount of recording time remaining.

To end recording, press the shutter-release button all the way down a second time.

Recording will automatically stop if the internal memory or memory card becomes full.



### Recording Movies

- Flash (28) and exposure compensation (32) can only be used for time-lapse and stop-motion movies. Macro close-up mode (31) is available in all modes. Self-timer (30) cannot be used.
- Digital zoom (up to 2×) can be applied while movies are being recorded. Adjust optical zoom before beginning recording.
- The maximum file size for movies is 2 GB.

# The Movie Menu

Press MENU in movie mode to display the movie menu.

| | | |
|---|---|---|
| | **Movie options** | 60 |
| | Choose type of movie that will be recorded. | |
| | **Auto-focus mode** | 61 |
| | Choose how camera focuses in movie mode. | |
| VR | **Electronic VR** | 61 |
| | Reduce effects of camera shake. | |

- To exit the movie menu, press MENU or shutter-release button.

## Selecting Movie Options

The movie menu offers the options shown below.

| Option | Image size and frame rate | Maximum movie length/frames* | |
|---|---|---|---|
| | | Internal memory (approx. 20 MB) | Memory card (256 MB) |
| TV movie 640★ | Image size: 640 × 480 pixels<br>Frame rate: 30 frames per second | 19 sec. | 3 min. 30 sec. |
| Small size 320★ | Image size: 320 × 240 pixels<br>Frame rate: 30 frames per second | 39 sec. | 7 min. 15 sec. |
| Small size 320 (default) | Image size: 320 × 240 pixels<br>Frame rate: 15 frames per second | 1 min. 17 sec. | 14 min. 15 sec. |
| Smaller size 160 | Image size: 160 × 120 pixels<br>Frame rate: 15 frames per second | 4 min. 16 sec. | 47 min. |
| Time-lapse movie★ | The camera automatically takes pictures at intervals and joins them into a silent movie (62).<br>Image size: 640 × 480 pixels<br>Frame rate: 30 frames per second | 233 frames | 1,800 frames |
| Stop-motion movie | Pictures can be taken and joined into a silent movie (63).<br>Image size: 640 × 480 pixels<br>Frame rate: choose from five, ten, or 15 frames per second | 233 frames | 1,800 frames |

* All figures are approximate. Maximum movie length varies with make of memory card. The maximum file size for movies is 2 GB. However, when recording to the internal memory, or memory cards with capacities of less than 2 GB, the time remaining display indicates the amount of free space remaining in the internal memory or memory card. When 4-GB memory cards are used, up to two 2-GB movies can be recorded, and the time remaining display indicates the amount of time until the maximum 2-GB file size will be recorded.

## Auto-Focus Mode

Choose how the camera focuses in movie mode.

| Option | Description |
|---|---|
| AF-S Single AF (default setting) | Camera focuses when shutter-release button is pressed halfway and locks at this position during shooting. |
| AF-F Full-time AF | Camera constantly adjusts focus, even when shutter-release button is not pressed.<br>To prevent sound of camera focusing from interfering with recording, use of [Single AF] is recommended. |

## Electronic VR

Choose [On] to reduce the effects of camera shake in all movie modes except [Time-lapse movie★] and [Stop-motion movie].

At settings other than [Off], an electronic VR indicator is displayed in the monitor (6).






**Movie File Names and Folder Names**

See "Image/Sound File and Folder Names" (115).

## Time-Lapse Movies

Use for time-lapse movies of such subjects as flowers opening or butterflies emerging from cocoons.

**1** Use the multi selector to choose [Movie options] and press ⓞ.




**2** Choose [Time-lapse movie★] and press ⓞ.




**3** Choose the interval between shots and press ⓞ.

Choose from intervals between 30 seconds and 60 minutes.




**4** Press MENU.

The camera returns to shooting mode.




**5** Press the shutter-release button all the way down to start recording.

Monitor turns off and power-on lamp blinks between shots.
Monitor reactivates automatically for the next shot.

**6** Press the shutter-release button all the way down a second time to end recording.

Recording will automatically stop if the internal memory or memory card becomes full, or when 1,800 frames have been recorded. A 1,800-frame movie has a playback time of 60 seconds.

## Stop-Motion Movies

**1** Use the multi selector to choose [Movie options] > [Stop-motion movie] and press ⓞ.




**2** Choose [Playback speed] and press ⓞ.




**3** Press MENU.

The camera returns to shooting mode.

**4** Press the shutter-release button to record the first frame.

The recorded picture will be superimposed on the view through the lens.

**5** Press the shutter-release button to record the second frame.

Use the frame superimposed in the camera monitor as a guide for recording consecutive frames.

The monitor turns off automatically with the auto off function (📖 109) if no operations are performed for 30 minutes, and recording ends.

**6** Press ⓞ to end recording.

Recording will automatically stop if the internal memory or memory card becomes full, or when 1,800 frames have been recorded.

### Time-Lapse Movie and Stop-Motion Movie

- Flash mode (📖 28), macro close-up mode (📖 31), and exposure compensation (📖 32) cannot be adjusted after the first picture is taken. Apply the appropriate settings before shooting begins.
- To prevent the camera from turning off unexpectedly during recording, use a fully charged battery.
- To power the camera continuously for extended periods, use an AC Adapter EH-62D (available separately from Nikon) (📖 114). ***Do not, under any circumstances, use another make or model of AC adapter***. Failure to observe this precaution could result in overheating or in damage to the camera.

# Movie Playback

In full-frame playback (26), movies are recognized by the icon. To play a movie, display it in full-frame playback and press OK.

During playback

Use the zoom buttons to adjust playback volume. Press **W** to lower volume, or **T** to raise volume.

Playback controls appear at the top of the monitor. Press the multi selector left or right to choose a control, then press OK to perform the selected operation. The following operations are available:




| To | Press | Description | |
|---|---|---|---|
| Rewind | ◀◀ | Rewind movie. Playback resumes when OK is released. | |
| Advance | ▶▶ | Advance movie. Playback resumes when OK is released. | |
| Pause | II | Pause playback.<br>While paused, use the multi selector to advance or rewind the movie. The following operations can be performed while playback is paused. | |
| | | ◀II | Rewind movie by one frame. Rewind continues while OK is pressed. |
| | | II▶ | Advance movie by one frame. Advance continues while OK is pressed. |
| | | ▶ | Resume playback. |
| | | ■ | End playback and return to full-frame playback. |
| End | ■ | End playback and return to full-frame playback. | |

## Deleting Movie Files

Press 🗑 during movie playback, when displayed in full-frame playback (26), or when selected in thumbnail (45) playback. A confirmation dialog is displayed. Choose [Yes] and press OK to delete the movie, or choose [No] and press OK to return to the normal playback display without deleting the movie.



# Making Voice Recordings

Audio voice recordings can be recorded over the built-in microphone and played back over the built-in speaker.
Voice recordings of about 47 minutes in the memory or up to five hours on the memory card (256 MB or more) are available.

## 1 Enter voice recording mode by pressing MODE in shooting mode, selecting (use the multi selector), and then pressing OK.



The length of recording that can be made will be displayed.




## 2 Press the shutter-release button all the way down to start recording.

Flash lamp lights while recording is in progress. When camera enters stand-by mode (21), press ▶ to reactivate display.




## 3 Press the shutter-release button all the way down a second time to end recording.

Recording will end automatically if the internal memory or memory card becomes full, or after five hours of recording on the memory card.

### Operations During Recording

The following operations are available during recording. If the monitor has turned off, press ▶ to reactivate.

| To | Press | Description |
|---|---|---|
| Pause/resume recording | OK | Press once to pause recording; flash lamp will blink. |
| Create index | | During recording, press the multi selector to create index. Camera can skip to any index during playback. Start of recording is index number 1; other numbers are assigned in ascending order, to a maximum of 98. |
| End recording | | Press the shutter-release button all the way down a second time to end recording. |



**Voice Recordings**

- PictureProject cannot be used to transfer or play voice recordings. Select [Interface] > [Mass storage] for [USB], copy the files manually.
- The copied files can be played back using QuickTime or any other WAV-compatible audio player.
- Note that index points created with the camera cannot be used when voice recordings are played back on computers.

# Playing Voice Recordings

**1** Enter audio playback mode by pressing MODE in playback mode, selecting (use the multi selector), and then pressing OK.



**2** Choose the desired file and press OK.

The selected file will be played back.







### Audio playback Mode

Audio playback mode can be entered by pressing ▶ button in the voice recording mode (65).



## Operations During Playback

Use the zoom buttons to adjust playback volume. Press **W** to lower volume, or **T** to raise volume.

Playback controls appear at the top of the monitor. Press the multi selector to left or right to choose a control, then press ⓞ to perform the selected operation. The following operations are available:

| To | Press | Description |
|---|---|---|
| Rewind | ◀◀ | Rewind voice recording. Playback resumes when ⓞ is released. |
| Advance | ▶▶ | Advance voice recording. Playback resumes when ⓞ is released. |
| Skip to previous index | ⏮ | Skip to previous index. |
| Skip to next index | ⏭ | Skip to next index. |
| Pause | ⏸ | Pause playback. |
| Resume | ▶ | Resume playback. |
| End | ■ | End playback and return to full-frame playback. |



### Deleting Sound Files

Press 🗑 during playback or after selecting a sound file (use the multi selector). A confirmation dialog will be displayed. To delete the file, choose [Yes] and press ⓞ. To cancel deletion, choose [No] and press ⓞ.

# Copying Voice Recordings

Copy voice recordings between the internal memory and a memory card. This option is available only when a memory card is inserted.

**1** Press MENU in the select sound file screen (📖 67, step 2).




**2** Use the multi selector to choose the option and press OK.




🏠→📁: Copy recordings from internal memory to memory card

📁→🏠: Copy recordings from memory card to internal memory

**3** Choose the copy option and press OK.




[Selected files]: Proceed to step 4

[Copy all files]: Proceed to step 5

**4** Choose the desired file.




Press the multi selector to right to select the file (✔). Press the multi selector to right again to cancel the selection.

- Multiple files can be selected.
- Press OK to finalize file selection.

A confirmation dialog will be displayed.

**5** Choose [Yes] and press OK.

Copying starts.

### Voice Recordings

The COOLPIX S200 may be unable to play or copy sound files created with another make of camera.

### [No sound file.] Message

If there are no sound files stored on the memory card when 🎤 is selected (📖 67, step1), the message, [No sound file.], will be displayed. Press MENU to display the copy sound files screen, and copy the sound files stored in the camera's internal memory to the memory card.

# Connecting to a TV

Connect the camera to a television using the A/V cable to play back pictures on the television.

**1** Turn off the camera.




**2** Connect the camera to the TV using the supplied A/V cable.
Connect the yellow plug to the video-in jack on the TV, and the white plug to the audio-in jack.




**3** Tune the television to the video channel.
See the documentation provided with your television for details.

**4** Hold down ▶ to turn on the camera.

The camera enters playback mode, and the pictures taken will be displayed on the television.

While connected to the TV, the camera monitor will remain off.




### ☑ Before Connecting the Camera

Use a fully charged battery or the AC Adapter EH-62D (available separately from Nikon) to prevent the camera from turning off unexpectedly while connected.

### ☑ Connecting an A/V Cable

When connecting the A/V cable, be sure that the camera connector is oriented correctly. Do not use force when connecting the A/V cable to the camera. When disconnecting the A/V cable, do not pull the connector at an angle.

### ☑ Video Mode

Be sure that the camera's video mode setting conforms to the standard used by your television. The video mode setting is an option set in the setup menu (📖 100) > [Interface] (📖 111) > [Video mode].

# Connecting to a Computer

Use the supplied USB cable to connect the camera to a computer, and copy (transfer) pictures to a computer with the supplied PictureProject software.

## Before Connecting the Camera

### Installing PictureProject

Before transferring pictures or movies to a computer, PictureProject must be installed. For more information on installing and using PictureProject, see the *Quick Start Guide* or the *PictureProject Reference Manual* (on CD).

### Confirming USB Option

The following two methods can be used to transfer pictures from the camera to a computer:

- Click [Transfer] in PictureProject.
- Press ↷ (OK) on the camera.

The method used will depend on your computer's operating system and the USB option selected in the camera's setup menu.

| Operating system[1] | USB mode[2] | |
|---|---|---|
| | ↷ (OK) on the camera[3] | [Transfer] in PictureProject |
| Windows Vista (32-bit HomeBasic/ HomePremium/Business/Enterprise/Ultimate editions) | Choose [Mass storage]. | Choose [MTP/PTP] or [Mass storage]. |
| Windows XP (Home Edition /Professional) | Choose [MTP/PTP] or [Mass storage]. | |
| Windows 2000 Professional[4] | Choose [Mass storage]. | |
| Mac OS X (Version 10.3.9, 10.4.x) | Choose [MTP/PTP]. | Choose [MTP/PTP] or [Mass storage]. |

1 Refer to the Nikon website for the latest information on operating system compatibility.
2 This camera supports the USB options, [MTP/PTP] (default setting) and [Mass storage].
3 The camera's ↷ (OK) button cannot be used to transfer pictures in the following cases. Use [Transfer] in PictureProject.
- When transferring pictures from the camera's internal memory and [Mass storage] is selected in the USB menu.
- When the memory card write-protect switch is in the "lock" position. Unlock by sliding the switch to the "write" position before transferring pictures.

4 If your computer is running Windows 2000 Professional, be sure to set the USB option to [Mass storage]. If [MTP/PTP] is selected, the [Found New Hardware Wizard] will be displayed when the camera is connected to the computer. Select [Cancel], close the window, and disconnect the camera from the computer.

## Setting the USB Option

Set the USB option in the setup menu (📖 100) on the camera before connecting the camera to a computer or printer.

**1** Display the setup menu by pressing MODE in playback or shooting mode, selecting (use the multi selector), and then pressing OK.




**2** Choose [Interface] and press OK.




**3** Choose [USB] and press OK.




**4** Choose [MTP/PTP] or [Mass storage] and press OK (📖 71).

The setting is enabled.

Press MODE to exit setup menu.



## Transferring Pictures to a Computer

**1** Start a computer to which PictureProject has been installed.

**2** Turn off the camera.

**3** Connect the camera to the computer using the supplied USB cable.



**4** Turn on the camera.

At default PictureProject settings, PictureProject Transfer is launched immediately with recognition of camera connection.




**5** Transfer pictures.

### Transfer using PictureProject

Click [Transfer] in PictureProject Transfer.

All pictures and movies marked for transfer are copied to the computer. Once transfer is complete, pictures are displayed in PictureProject.

### Transfer using ↷ (OK) on the camera

While PictureProject Transfer is launched, press ↷ (OK) to copy pictures marked for transfer (98, 111) to the computer. The following messages are displayed in the camera monitor during transfer.

## 6 Disconnect the camera when transfer is complete.

### If the USB option is set to [MTP/PTP]

Turn the camera off and disconnect the USB cable.

### If the USB option is set to [Mass storage]

Remove the camera from the system as described below before turning the camera off and disconnecting the USB cable.

**Windows Vista/Windows XP**

Click the [Safely Remove Hardware] icon in the taskbar and select [Safely remove USB Mass Storage Device] from the menu displayed.

**Windows 2000 Professional**

Click the [Unplug or Eject Hardware] icon in the taskbar and select [Stop USB Mass Storage Device] from the menu displayed.

**Macintosh**

Drag the untitled camera volume ("NO NAME") to the Trash.

### Connecting the USB Cable

- When connecting the USB cable, be sure that the connectors are oriented correctly. Do not use force when connecting the USB cable. When disconnecting the USB cable, do not pull the connector at an angle.
- Connection may not be recognized when the camera is connected to a computer via a USB hub.

### Marking Pictures for Transfer

When ↷ (OK) button is pressed while the camera is connected to a computer, pictures marked with the ↷ (OK) icon during playback will be transferred to the computer. As the default setting, all pictures are automatically marked for transfer. Two options control transfer marking:




- [Interface] > [Auto transfer] in the setup menu (📖 111): Choose [On] to mark *all new pictures* for transfer (default setting).
- [Transfer marking] in the playback menu (📖 98): Change marking for *existing pictures*.

# Connecting to a Printer

Users of PictBridge-compatible (131) printers can connect the camera directly to the printer and print pictures without using a computer.






### Printing Pictures

In addition to printing pictures transferred to a computer from your personal printer and printing over a direct camera-to-printer connection, the following options are also available for printing pictures:

- Insert a memory card into a DPOF-compatible printer's card slot
- Take a memory card to a digital photo lab

For printing using these methods, specify the pictures and the number of prints each using your camera's print set menu (81).

## Connecting the Camera and Printer

**1** Set the USB option (72) to [MTP/PTP].




**2** Turn off the camera.




**3** Turn on the printer.
Check printer settings.

**4** Connect the camera to the printer using the supplied USB cable.



**5** Turn on the camera.
When connected correctly, the PictBridge start-up screen ① will be displayed in the camera monitor. Then the print selection screen will be displayed ②.




①


② 


### Connecting the USB Cable

When connecting the USB cable, be sure that the connectors are oriented correctly. Do not use force when connecting the USB cable. When disconnecting the USB cable, do not pull the connector at an angle.

## Printing Pictures One at a Time

After connecting the camera to the printer correctly (76), print pictures by following the procedure below.

**1** Press the multi selector to left or right to choose the desired picture and press ⓞ.

The PictBridge menu is displayed.

Press **T** (Q) to switch to full-frame playback.

Press **W** (▦) to switch back to thumbnail display.




**2** Choose [Copies] and press ⓞ.




**3** Choose the number of copies (up to nine) and press ⓞ.




**4** Choose [Paper size] and press ⓞ.




**5** Choose the desired paper size and press ⓞ.

To specify paper size using printer settings, choose [Default] in the paper size menu and press ⓞ.



**6** Choose [Start print] and press ⓞ.




**7** Printing starts.

Monitor display returns to that shown in step 1 when printing is complete.

To cancel before all copies have been printed, press ⓞ.




Current print/
total number of prints

## Printing Multiple Pictures

After connecting the camera to the printer correctly (76), print pictures by following the procedure below.

**1** When the print selection screen is displayed, press MENU.

The print menu is displayed.




**2** Use the multi selector to choose [Paper size] and press ⓞ.



## 3 Choose the desired paper size and press ⓞ.

To specify paper size using printer settings, choose [Default] in the paper size menu and press ⓞ.




## 4 Choose [Print selection], [Print all images] or [DPOF printing] and press ⓞ.




**Print selection**

Select pictures and specify the number of prints for each picture. Proceed to step 5.

**Print all images**

All pictures stored in the internal memory or memory card are printed. Proceed to step 7.

**DPOF printing**

Print pictures for which a print order has been created in [Print set] (81).

- The menu shown at right will be displayed.
- To print, choose [Start print] and press ⓞ. Proceed to step 7.
- To view the current print order, choose [View images] and press ⓞ. To print pictures, press ⓞ again. Proceed to step 7.
- Select [Cancel] and press ⓞ to return to the print menu (step 4).






## 5 Press the multi selector to left or right to select pictures




## 6 Press the multi selector up or down to set the number of copies (up to nine)




Pictures selected for printing can be recognized by the check mark (✔) and the numeral indicating the number of copies to be printed. A check mark is not displayed with pictures for which 0 copies have been specified and these pictures will not be printed.

Repeat steps 5–6 to select additional pictures.

Press **T** (Q) to switch to full-frame playback.

Press **W** (▪▪▪) to switch back to thumbnail display.

Press ⓞ when setting is complete.

## 7 Printing starts.

Monitor display returns to the print menu (step 2) when printing is complete.

To cancel before all copies have been printed, press ⓞ.



### Paper Size

The camera supports the following paper sizes: [Default] (the default paper size for the current printer), [3.5 × 5 in.], [5 × 7 in.], [Postcard], [100 × 150 mm], [4 × 6 in.], [8 × 10 in.], [Letter], [A3], and [A4]. Only sizes supported by the current printer will be displayed. To specify paper size using printer settings, choose [Default] in the paper size menu.

# Creating a DPOF Print Order: Print Set

The [Print set] option in the playback menu is used to create digital "print orders" for printing on DPOF-compatible devices (131).

In addition to pictures themselves, shooting date and photo information (shutter speed, aperture, etc.) can also be printed.

When the camera is connected to a PictBridge-compatible printer, pictures can be printed from the printer according to the DPOF print order you have created for pictures on the memory card. If the memory card is removed from the camera, you can create the DPOF print order for pictures in the internal memory and print pictures according to the DPOF print order.

**1** Press MENU in playback mode.

The playback menu is displayed.

**2** Use the multi selector to choose [Print set] and press OK.

The print set menu is displayed.




**3** Choose [Print selected] and press OK.




**4** Press the multi selector to left or right to select pictures

**5** Press the multi selector up or down to set the number of copies (up to nine)




Pictures selected for printing can be recognized by the check mark (✔) and the numeral indicating the number of copies to be printed. A check mark is not displayed with pictures for which 0 copies have been specified and these pictures will not be printed.

Repeat steps 4–5 to select additional pictures.

Press **T** (Q) to switch to full-frame playback.

Press **W** (▦) to switch back to thumbnail display.

Press OK when setting is complete.

## 6 Choose whether or not to also print shooting date and photo information.




[Date]: Print date of recording on all pictures in the print order.

[Info]: Print shutter speed and aperture on all pictures in the print order. Note that this information is not printed with direct connection to a printer.

[Done]: Complete the print order and exit.

Pictures selected for printing are recognized by the 🖶 icon displayed with playback.




### Print Set

[Date] and [Info] are reset each time the print set menu is displayed.

### Deleting All Print Orders

Choose [Delete print set] in step 3 and press ⊛. Print orders for all pictures will be deleted.

### Note on the Print Set [Date] Option

The date and time printed on pictures with DPOF printing when [Date] in the print set menu is enabled are those recorded with the picture when it was taken. Date and time printed using this option are not affected when the camera's date and time setting are changed from the setup menu after pictures are recorded.

### Differences Between Print Set and Date Imprint

Date and time can only be printed on pictures using the [Date] option in the print set menu when pictures are printed from a DPOF-compatible printer (131). Use the [Date imprint] (107) option in the setup menu to print the date on pictures from a printer that does not support DPOF (position of the date is fixed). When the date option for both [Print set] and [Date imprint] is enabled, only the date from the [Date imprint] option is printed, even when a DPOF-compatible printer is used.

# Shooting Options: The Shooting Menu

The shooting menu contains the following options.

| | | |
|---|---|---|
| | **Image mode** | 84 |
| | Choose image size and quality. | |
| WB | **White balance*** | 86 |
| | Match white balance to the light source. | |
| | **Continuous*** | 88 |
| | Take pictures one at a time or in a sequence. | |
| BSS | **BSS*** | 90 |
| | Use the "best shot selector" to choose the sharpest picture. | |
| ISO | **ISO sensitivity** | 91 |
| | Control camera's sensitivity to light. | |
| | **Color options*** | 91 |
| | Apply color effects to pictures as they are recorded. | |
| VR | **Electronic VR** | 92 |
| | Choose whether or not to apply electronic vibration reduction to reduce camera shake while taking pictures. | |

* See the information on restrictions that may apply to these settings (93).



### High-sensitivity Modes

In high-sensitivity shooting mode, pressing MENU displays the high-sensitivity menu. The items available from this menu are the same as those available in the (auto) mode shooting menu (83), except that [ISO sensitivity] and [Electronic VR] are not available in the high-sensitivity menu.

## Displaying the Shooting Menu and High-sensitivity Menu

Enter (auto) or high-sensitivity shooting mode by pressing MODE in shooting mode, selecting (auto) or (high-sensitivity), and then pressing OK. Press MENU to display the shooting menu or high-sensitivity menu.




- Use the multi selector (10) to choose and apply settings.
- To exit the shooting or high-sensitivity menu, press MENU.

### Image Mode




Pictures taken with a digital camera are recorded as image files. The size of the files, and with it the number of images that can be recorded, depends on the size and quality of the images. Before shooting, choose an image mode according to how you plan to use the picture.

| Option | Size (pixels) | Description |
|---|---|---|
| High (3072★) | 3,072 × 2,304 | Highest quality, suitable for enlargements or high-quality prints. The compression ratio is approximately 1:4. |
| Normal (3072) (default setting) | 3,072 × 2,304 | Best choice in most situations. The compression ratio is approximately 1:8. |
| Normal (2592) | 2,592 × 1,944 | |
| Normal (2048) | 2,048 × 1,536 | Smaller size allows more pictures to be stored. The compression ratio is approximately 1:8. |
| PC screen (1024) | 1,024 × 768 | Suited to display on computer monitor. The compression ratio is approximately 1:8. |
| TV screen (640) | 640 × 480 | Suited to full-screen display on a television or distribution by e-mail or the web. The compression ratio is approximately 1:8. |
| 16:9 | 3072 × 1728 | Pictures with an aspect ratio of 16:9 can be taken. The compression ratio is approximately 1:8. |

The icon for the current setting is displayed in the monitor in shooting and playback modes (6, 7).

### Image Mode and the Number of Exposures Remaining

The following table lists the number of pictures that can be stored in internal memory and on a 256 MB memory card, together with the size of still pictures. Note that the number of pictures that can be stored will differ depending on the composition of the picture (due to JPEG compression). In addition, this number may differ depending on the make of memory card, even if the capacity for the memory card is the same.

| Setting | | Internal memory (approx. 20 MB) | Memory card[1] (256 MB) | Print size (printed at 300 dpi; cm/in.)[2] |
|---|---|---|---|---|
| ⁷ᴹ | High (3072★) | 6 | 70 | 26 × 19.5/10.4 × 7.8 |
| ⁷ᴹ | Normal (3072) | 12 | 135 | 26 × 19.5/10.4 × 7.8 |
| ⁵ᴹ | Normal (2592) | 17 | 190 | 22 × 16.5/8.8 × 6.6 |
| ³ᴹ | Normal (2048) | 27 | 300 | 17 × 13/6.8 × 5.2 |
| PC | PC screen (1024) | 93 | 1025 | 9 × 7/3.6 × 2.8 |
| TV | TV screen (640) | 175 | 1925 | 5 × 4/2 × 1.6 |
| 16:9 | 16:9 | 16 | 180 | 26 × 14.5/10.4 × 5.7 |

[1] All figures are approximate. If the number of exposures remaining is 10,000 or more, the number of exposure remaining display shows [9999].

[2] All figures are approximate. The size of images when printed depends on the printer resolution: the higher the resolution, the smaller the final print size.

### Image Mode

The image mode setting can also be applied from the scene menu, anti-shake shooting mode, and one-touch portrait menu. Changes made to the image mode setting from any of the three menus apply to all shooting modes.

## WB White Balance

The color of light reflected from an object varies with the color of the light source. The human brain is able to adapt to changes in the color of the light source, with the result that white objects appear white whether seen in the shade, direct sunlight, or under incandescent lighting. Digital cameras can mimic this adjustment by processing images according to the color of the light source. This is known as "white balance." For natural coloration, choose a white balance setting that matches the light source before shooting. Although the default setting, [Auto], can be used under most types of lighting, you can apply the white balance setting suited to a particular light source to achieve more accurate results.

| | |
|---|---|
| AUTO | Auto (default setting) |
| | White balance automatically adjusted to suit lighting conditions. Best choice in most situations. |
| PRE | White bal. preset |
| | Neutral-colored object used as reference to set white balance under unusual lighting conditions (87). |
| ☀ | Daylight |
| | White balance adjusted for direct sunlight. |
| 💡 | Incandescent |
| | Use under incandescent lighting. |
| ▦ | Fluorescent |
| | Use under most types of fluorescent lighting. |
| ☁ | Cloudy |
| | Use when taking pictures under overcast skies. |
| ⚡ | Flash |
| | Use with the flash. |

At settings other than [Auto], the icon for the current setting is displayed in the monitor (6).

### Flash Mode

At white-balance settings other than [Auto] or [Flash], turn the flash off (⊘) (28).

### PRE Preset White Balance

Preset white balance is used with mixed lighting or to compensate for light sources with a strong color cast (for example, to make pictures taken under a lamp with a red shade look as though they had been taken under white light).

**1** Place a white or gray reference object under the lighting that will be used during shooting.

**2** Use the multi selector to choose [White bal. preset] in the white balance menu, and press OK.

The camera zooms in.




**3** Choose [Measure].

To apply the most recently measured value for preset white balance, choose [Cancel] and press OK.




**4** Frame the reference object.




Reference object frame

**5** Press OK.

The shutter is released and the new white balance value is set.

No pictures are recorded.

#### Note on Preset White Balance

Regardless of the flash mode selected, the flash will not fire when OK is pressed in step 5. Therefore, the camera cannot measure a value for preset white balance for when the flash is used.

## Continuous

Capture a fleeting expression on a portrait subject, photograph a subject that is moving unpredictably, or capture motion in a series of pictures. Focus, exposure, and white balance are fixed at the values for the first picture in each series.

**Single (default setting)**

One shot is taken each time shutter-release button is pressed.

**Continuous**

While the shutter-release button is held down, pictures are taken at rate of about 1.3 frames per second (fps). This rate is maintained for up to 6 pictures when image mode is set to [ Normal (3072)].

**Multi-shot 16**

Each time shutter-release button is pressed, camera takes 16 shots at about 1.6 frames per second and arrange them in a single picture Normal (2592) pixels as shown at right.



**Intvl timer shooting**

Camera takes pictures (up to 1,800 frames) automatically at specified interval.

At settings other than [Single], the icon for the current setting is displayed in the monitor ( 6).

### Interval Timer Photography

Pictures are taken automatically at specified intervals. Choose from intervals between 30 seconds and 60 minutes.

**1** Use the multi selector to choose [Intvl timer shooting] in the continuous menu, and press OK.




**2** Choose interval between shots and press OK.




**3** Press MENU.

The camera returns to shooting mode.

**4** Press the shutter-release button all the way down to start recording.

Monitor turns off and power-on lamp blinks between shots.

The monitor turns on automatically right before the next shot is taken.




**5** Press the shutter-release button all the way down a second time to end recording.

Recording will end automatically if the internal memory or memory card becomes full, or when 1,800 pictures have been taken.

### Power Source

- To prevent the camera from turning off unexpectedly during recording, use a fully charged battery.
- To power the camera continuously for extended periods, use an AC Adapter EH-62D (available separately from Nikon) (114). ***Do not, under any circumstances, use another make or model of AC adapter***. Failure to observe this precaution could result in overheating or in damage to the camera.

## BSS Best Shot Selector (BSS)

The "best shot selector" is convenient for shooting in situations where inadvertent camera movement can result in blurred pictures.

At [On] setting, the flash automatically turns off and focus, exposure, and white balance for all pictures are determined by the first picture in each series.

| | |
|---|---|
| BSS | On |
| | Recommended for taking pictures in poorly lit places, or in other situations where camera shake may occur. Camera takes shots while shutter-release button is pressed, to a maximum of ten. These images are then compared and the sharpest picture (picture with highest level of detail) is saved. |
| OFF | Off (default setting) |
| | Only one picture is taken. |

When BSS is [On], a BSS icon appears in the monitor (6).



**Note on Best Shot Selector**

BSS may not produce the desired results if the subject moves or the composition changes while the shutter-release button is pressed all the way down.

## ISO Sensitivity

Sensitivity is a measure of how quickly the camera reacts to light. The higher the sensitivity, the less light needed to make an exposure. Although a high ISO rating is suited for taking pictures of subjects in action or in poor lighting, high sensitivity is often associated with "noise" –randomly spaced, brightly colored pixels concentrated in dark parts of the image.

[Auto] (default setting) is ISO 50 under normal conditions; when lighting is poor and the flash is off, the camera compensates by raising sensitivity to a maximum of ISO 800. Choose from values between ISO 50 and 1000.

At settings other than [Auto], the current setting is displayed in the monitor (6). If [Auto] is selected and the sensitivity is raised above an ISO 50, the ISO icon will be displayed (6, 29).

## Color Options

Make colors more vivid or record pictures in monochrome.

| | |
|---|---|
| | **Standard color (default setting)** |
| | Use for pictures exhibiting natural color. |
| VI | **Vivid color** |
| | Use to achieve a vivid, "photoprint" effect. |
| BW | **Black-and-white** |
| | Record pictures in black-and-white. |
| SE | **Sepia** |
| | Record pictures in sepia tones. |
| C | **Cyanotype** |
| | Record pictures in cyan-blue monochrome. |

The effects of the selected option can be previewed in the monitor. At settings other than [Standard color], the icon for the current setting is displayed in the monitor (6).

## Electronic VR




When set to [Auto], the affects of camera shake and blurred subjects are reduced while pictures are taken under the following conditions:

- Flash mode is set to ⊛ or ⊛
- Shutter speed is slow
- [Single] is selected in the continuous shooting menu

When [Electronic VR] is set to [Auto], the icon for the current setting is displayed in the monitor (📖 6).

### Electronic Vibration Reduction Icon

- The electronic VR may not work properly immediately after the camera is turned on or reactivated from standby mode.
- The electronic VR does not work when the exposure time is faster than a certain value.
- The electronic VR is less effective for when pictures are considerably blurred.
- Blurred subjects cannot be compensated.

### Notes on Electronic VR (📖 7, 49)

During playback, the compensated pictures are marked with a VR icon. If electronic vibration reduction cannot compensate blurring on shooting, a icon is displayed on the picture.

## Restrictions on Camera Settings

Restrictions apply to the following settings in (auto) mode:

**Flash mode**

Flash turns off at [Continuous] settings of [Continuous] or [Multi-shot 16], or when [BSS] is on. Applied setting is restored when [Single] or [Intvl timer shooting] is selected, or [BSS] is turned off.

**Self-timer**

If self-timer is on, only one shot will be taken when shutter is released, regardless of settings chosen for [Continuous] and [BSS]. Applied [Continuous] and [BSS] settings are restored when picture is taken or self-timer is turned off.

**Continuous**

Selecting [Continuous], [Multi-shot 16], or [Intvl timer shooting] turns [BSS] off.
Applied [BSS] setting is *not* restored when [Single] is selected.

**BSS**

[Continuous] is automatically set to [Single] when [On] is selected for [BSS].
Applied setting is *not* restored when [BSS] is turned off.

**White balance**

White balance is automatically set to [Auto] and cannot be adjusted when [Black-and-white], [Sepia], or [Cyanotype] is selected for [Color options].
Applied white balance setting is restored when [Standard color] or [Vivid color] is selected.

**Electronic VR**

[Date imprint] is automatically set to [Off] when [Auto] is selected for [Electronic VR].
[Electronic VR] is automatically set to [Off] when the option other than [Off] is selected for [Date imprint].

# Playback Options: The Playback Menu

The playback menu contains the following options.

| | | |
|---|---|---|
| | **D-Lighting** | 48 |
| | Enhance pictures brightening dark or backlit subject | |
| | **Print set** | 81 |
| | Select pictures to print and the number of copies for each. | |
| | **Slide show** | 96 |
| | View pictures stored in the internal memory or on a memory card in an automatic slide show. | |
| | **Delete** | 97 |
| | Delete all or selected pictures. | |
| | **Protect** | 98 |
| | Protect selected pictures from accidental deletion. | |
| | **Transfer marking** | 98 |
| | Mark existing pictures to transfer to a computer. | |
| | **Small pic.** | 51 |
| | Create a small copy of the current picture. | |
| | **Voice memo** | 52 |
| | Record and play voice memo. | |
| | **Copy** | 99 |
| | Copy files between memory card and internal memory. | |

## Displaying the Playback Menu

Display the playback menu by pressing ▶ and pressing MENU.




Select playback mode (26).

Press the MENU button.

- Use the multi selector to choose and apply settings. (9)
- To exit the playback menu, press MENU.

### Selecting Multiple Pictures

When following the steps below to select multiple pictures for a print set (📖 81), deletion (📖 97), protection from deletion (📖 98), transfer (📖 98), copying between internal memory and the memory card (📖 99), or for the welcome screen (📖 102), the screen shown at right is displayed. Follow the procedure described below to select multiple pictures.




**1** Press the multi selector to left or right to choose the desired picture.

Only one picture can be selected for [Welcome screen]. Proceed to step 3.

Press **T** (🔍) to switch to full-frame playback.

Press **W** (▦) to switch back to thumbnail display.




**2** Press the multi selector up or down to select [ON] or [OFF] (or the number of copies).

When [ON] is selected, a check mark (✔) is displayed in the top left corner of the current picture. Repeat steps 1 and 2 to select additional pictures.




**3** Press Ⓚ.

The setting is enabled.



## Slide Show

Play back pictures stored in the internal memory or on a memory card in an automated "slide show".




### 1 Display the slide show menu; use the multi selector to choose [Start] and press OK.




To change the interval between pictures, choose [Frame intvl], select the desired interval time, and press OK before choosing [Start].

To repeat the slide show automatically, enable [Loop] and press OK before choosing [Start]. The check mark (✔) will be added to the loop option when enabled.

### 2 The slide show begins.

While the slide show is in progress, the following operations can be performed:

- Press the multi selector to left or right to switch pictures. Keep the multi selector pressed to either direction to fast forward (right) or rewind (left).
- Press OK to pause the slide show.

The menu shown at right is displayed when the slide show ends or is paused. Choose [Restart] and press OK to play the slide show again, or choose [End] to stop the slide show and return to the playback menu.




### Notes on Slide Show

- Only the first frame of movies (64) included in slide shows is displayed.
- Even if [Loop] is selected, the monitor will turn off automatically if no operations are performed for 30 minutes. The camera will turn off automatically if no operations are performed for another three minutes.

## Delete

The delete menu contains the options shown below.

If no memory card is inserted in the camera, pictures in the internal memory will be deleted.

If a memory card is inserted, pictures on the memory card will be deleted.

**Erase selected images**

Delete selected pictures (95).

**Erase all images**

Delete all pictures stored in the internal memory or on the memory card.

- Choose [Yes] and press OK in the confirmation dialog to delete all pictures.
- To exit without deleting pictures, choose [No] and press OK.






### Notes on Deletion

- Once deleted, pictures cannot be recovered. Transfer important images to a computer before deletion.
- Pictures marked with the icon are protected and cannot be deleted.

## Protect




Protect selected pictures from accidental deletion. Note, however, that formatting will delete protected files (110).

**See "Selecting Multiple Pictures" (95) for more information on using this function.**

Protected pictures are recognized by the icon (7) in full-frame playback mode and the erase selected images screen, and by the icon (45) in 4- or 9-picture thumbnail playback mode.

## Transfer Marking

Change transfer marking ( ) for existing pictures. When the camera is connected to a computer with PictureProject installed via the supplied USB cable, pressing OK transfers only the pictures marked with a icon (73). At the default setting, all pictures are marked for transfer.

**All on**

Mark all images for transfer.

**All off**

Remove transfer marking from all images.

**Select Image(s)**

Mark selected pictures for transfer in the picture selection screen (95).

Pictures selected for transfer are recognized by the icon (7) in full-frame playback, and by the icon (45) in 4- or 9-picture thumbnail playback mode.

## Copy

Copy pictures between the internal memory and a memory card.

First, select from the following options.

**[IN] → [card]**

Copy pictures from internal memory to memory card.

**[card] → [IN]**

Copy pictures from memory card to internal memory.

Then, select the desired copy option.

Choose [Selected images] (95) to copy specific pictures in the internal memory or memory card. To copy all pictures, choose [All images].

### Notes on Copying Pictures

- If there is not enough space in the memory or on the memory card to receive the copy, an error message will be displayed. Delete unwanted pictures or insert a new memory card (if using a memory card) before trying again.
- The file format of images that can be copied is JPEG, AVI, or WAV.
- Pictures taken with another make of camera or that have been modified on a computer cannot be copied.

### [Memory contains no images.] Message

If there are no pictures stored on the memory card when playback mode is applied, the message, [Memory contains no images.], will be displayed. Press **MENU** to display the copy option screen, and copy the pictures stored in the camera's internal memory to the memory card.

### File Names of Copied Pictures (115)

- When pictures are copied using the [Selected images] option, the newly copied pictures are numbered consecutively from the largest number existing between the two memory sources.
  Ex: when the last number in the source memory is 32 (DSCN0032.JPG) and the last number in the destination memory is 18 (DSCN0018.JPG), the copied pictures are assigned numbers starting from DSCN0033.
- When pictures are copied using the [All images] option, all the pictures in the folder are copied with the same file numbers. New folder numbers are assigned in ascending order starting from the largest folder number available. If a new folder cannot be created, the folder is not copied and an error message will be displayed.

### Copies

Edited copies have the same protection marking (98) as the original but are not marked for printing (81) or transfer (98).

# Basic Camera Setup: The Setup Menu

The setup menu contains the following options.


| | | |
|---|---|---|
| MENU | **Menus** | 101 |
| | Choose how menus are displayed. | |
| | **Quick startup** | 102 |
| | Enable or disable welcome screen and start-up sound. | |
| | **Welcome screen** | 102 |
| | Select screen displayed when camera is turned on. | |
| | **Date** | 103 |
| | Set camera clock and choose home and destination time zones. | |
| | **Monitor settings** | 106 |
| | Adjust monitor brightness and choose display style. | |
| DATE | **Date imprint** | 107 |
| | Imprint date or date counter on pictures. | |
| | **Sound settings** | 109 |
| | Adjust sound and volume settings. | |
| | **Auto off** | 109 |
| | Set time before camera enters standby mode to save power. | |
| /[ ] | **Format memory/Format card** | 110 |
| | Format internal memory or memory card. | |
| | **Language** | 111 |
| | Choose language for camera menus and messages. | |
| | **Interface** | 111 |
| | Adjust settings for connection to television or computer. | |
| | **Reset all** | 112 |
| | Restore camera settings to default values. | |
| Ver. | **Firmware version** | 113 |
| | Display camera firmware version. | |

## Displaying the Setup Menu

First, display the playback-mode or shooting-mode selection menu by pressing MODE. Then select (use the multi selector), press OK.

- Use the multi selector to choose and apply settings. (10)
- To exit the setup menu, press MODE.

## Menus

Choose how menus are displayed.

When [Icons] is selected, all menu items can be displayed in a single page and the highlighted menu name appears at the top of the monitor.




[Text] [Icons]

## Quick Startup

Choose [On] (default setting) to disable the welcome screen and start-up sound. The camera will be ready for shooting as soon as it is turned on.

Set to [Off] when enabling the welcome screen.

## Welcome Screen

You can select the welcome screen to be displayed when the camera is turned on.

To set the welcome screen, [Quick startup] must be set to [Off].

**Nikon**

Displays a welcome screen when the camera is turned on.

**Animation (default setting)**

Displays a short animation when the camera is turned on.

**Select an image**

Select a picture in the internal memory or on the memory card for the welcome screen. Choose a picture in the picture selection screen (95), and press ⊛.

The image used in the welcome screen is a copy of the selected picture and, therefore, is not affected if the original picture is deleted or the memory card is removed.

- Pictures taken at an image mode setting of [16:9] (84) cannot be selected.

### When [Select an image] is Selected

If you have already selected a welcome screen picture, you can select a new one by following the confirmation dialog.



## Date

Set the camera clock and choose home and travel destination time zones.

**Date**

Set camera clock to current date and time.
See "Setting Display Language, Date, and Time" (16-17) for more information.

**Time zone**

(home time zone) can be specified and daylight saving enabled or disabled from [Time zone] options. When (destination time zone) is selected, the time difference (105) is automatically calculated and the date and time in the selected region are recorded. Useful when travelling.

### Setting Travel Destination Time Zone

**1** Use the multi selector to choose [Time zone] and press OK.

The time zone menu is displayed.




**2** Choose and press OK.

The date and time displayed on the monitor changes according to the region currently selected.

If daylight saving time is in effect, use the multi selector to choose [Daylight saving] and press OK, and then press ▲. The time is automatically advanced one hour.




**3** Press ▶.

The new city time zone menu is displayed.



## 4 Choose the travel destination time zone and press ⓞ.

The setting is enabled.

While the travel destination time zone is selected, the ✈ icon will be displayed in the monitor when the camera is in shooting mode.







### ☑ The Clock Battery

The clock battery charges when the main battery is installed or an AC adapter is connected, and can provide several days of backup power after about 10 hours of charging.

### ✎ ⌂ (Home Time Zone)

- To switch to the home time zone, choose ⌂ in step 2.
- To change the home time zone, choose ⌂ in step 2 and perform the following steps for the home time zone.

### ✎ Daylight Saving Time

- If date and time are set when daylight saving time is not in effect:
  Turn [Daylight saving] on (✔) when daylight saving time begins to automatically advance the camera's clock one hour.
- If date and time are set with [Daylight saving] turned on (✔) when daylight saving time is in effect:
  Turn [Daylight saving] off when daylight saving time ends to automatically set the camera's clock back one hour.

## Time Zones (16)

The camera supports the time zones listed below. Increments of less than one hour are not supported; when travelling to or from destinations at half- or quarter-hour increments from Greenwich Mean Time (GMT), such as Afghanistan, Central Australia, India, Iran, Nepal, or Newfoundland, set the camera clock to local time (16, 103).

| GMT +/– | Location | GMT +/– | Location |
|---|---|---|---|
| –11 | Midway, Samoa | +1 | Madrid, Paris, Berlin |
| –10 | Hawaii, Tahiti | +2 | Athens, Helsinki |
| –9 | Alaska, Anchorage | +3 | Moscow, Nairobi |
| –8 | PST (PDT): Los Angeles, Seattle, Vancouver | +4 | Abu Dhabi, Dubai |
| –7 | MST (MDT): Denver, Phoenix, La Paz | +5 | Islamabad, Karachi |
| –6 | CST (CDT): Chicago, Houston, Mexico City | +6 | Colombo, Dhaka |
| –5 | EST (EDT): New York, Toronto, Lima | +7 | Bangkok, Jakarta |
| –4 | Caracas, Manaus | +8 | Beijing, Hong Kong, Singapore |
| –3 | Buenos Aires, São Paulo | +9 | Tokyo, Seoul |
| –2 | Fernando de Noronha | +10 | Sydney, Guam |
| –1 | Azores | +11 | New Caledonia |
| ±0 | London, Casablanca | +12 | Auckland, Fiji |

## Monitor Settings

Choose whether or not to display information in the monitor, and set the monitor brightness.

**Photo info**

Choose information displayed in monitor during shooting and playback mode.

**Brightness**

Choose from five settings for monitor brightness.

### Photo Info

The following display options are available.

See "The Monitor" (6,7) for information on indicators in the monitor.

| | Shooting mode | Playback mode |
|---|---|---|
| Show info |  |  |
| Auto info (default setting) | The current settings or operation guide is displayed for five seconds as in [Show info] above. After five seconds, display will be the same as [Hide info]. | |
| Hide info | | |
| Framing grid | <br>In (auto) mode or high-sensitivity shooting mode, a framing grid is displayed to help frame pictures; other current settings or operation guide is displayed for five seconds as in [Auto info] above.<br>In other shooting modes, the current settings or operation guide is displayed as in [Auto info] above. |  <br>The current settings or operation guide is displayed as in [Auto info] above. |

## Date Imprint

Date and time of recording can be imprinted on pictures for printing this information from printers that are not DPOF-compatible (131).

**Off (default setting)**

Date and time are not imprinted on pictures.

**Date**

Date is imprinted on the bottom right corner of pictures taken while this option is in effect.

**Date and time**

Date and time are imprinted on the bottom right corner of pictures taken while this option is in effect.

**Date counter**

Time stamp shows number of days between date of recording and selected date.

At settings other than [Off], the icon for the current setting is displayed in the monitor (6).

### Date Imprint

- Imprinted dates form a permanent part of image data and cannot be deleted.
- Dates imprinted at an image-mode setting (84) of [TV screen (640)] may be difficult to read. Choose [PC screen (1024)] or larger when using date imprint.
- The date is recorded using the format selected in the setup menu's [Date] item (16, 103).

### Date Imprint and Print Set

When using DPOF-compatible devices, shooting date or photo information will be printed if [Date] or [Info] is selected in the print set menu (81). See "Differences Between Print Set and Date Imprint" (82) for more information on the difference between [Date imprint] and [Print set].

## Date Counter

Pictures taken while this option is in effect are imprinted with the number of days remaining until, or the number of days elapsed since a specified date. Use it to track the growth of a child or count down the days until a birthday or wedding.




### Stored dates

Up to three dates can be stored. To set, choose an option, press the multi selector to right, enter a date (16), and press OK. To select a different date, choose an option and press OK.




### Display options

Choose [Number of days], [Years and days], or [Yrs, mnths, days] and press OK.




Sample date counter time stamps are shown below.

Two days remaining

Two days elapsed

## Sound Settings

Adjust the following sound settings.

**Button sound**

When [On] (default setting) is selected, beep will sound once when operations are completed successfully, three times when error is detected.

**Shutter sound**

Choose shutter sound from [1] (default setting), [2], [3], and [Off].

**Volume**

Choose volume of shutter sound and start-up sound (📖 102) from [Loud], [Normal] (default setting), and [Off].

## Auto Off

Choose the time allowed to elapse before the camera enters standby mode to save power (📖 21). The time options are [30s], [1m] (default setting), [5m], and [30m]. The power-on lamp flashes in standby mode. If no operations are performed for another three minutes, the camera turns off.



### Notes on Auto Off

The monitor will remain on for:

- Three minutes when menus are displayed
- 30 minutes during continuous playback for slide shows

## Format Memory/Format Card

Use this option to format the internal memory or a memory card.

### Formatting the Internal Memory

To format the internal memory, remove the memory card from the camera.

The [Format memory] option appears in the setup menu.




### Formatting a Memory Card

When the memory card is inserted in the camera, the [Format card] option appears in the setup menu.






### Formatting Internal Memory and Memory Cards

- Formatting the internal memory or memory cards permanently deletes all data. Be sure to transfer important pictures to a computer before formatting.
- Do not turn the camera off, disconnect the AC charger, or remove the battery or memory card during formatting.
- The first time you insert the memory cards used in other devices into the COOLPIX S200, format them.

## Language

Choose one of 20 languages for display of camera menus and messages.

| | |
|---|---|
| **Čeština** | Czech |
| **Dansk** | Danish |
| **Deutsch** | German |
| **English** | (default setting) |
| **Español** | Spanish |
| **Français** | French |
| **Indonesia** | Indonesian |
| **Italiano** | Italian |
| **Nederlands** | Dutch |
| **Norsk** | Norwegian |
| **Polski** | Polish |
| **Português** | Portuguese |
| **Русский** | Russian |
| **Suomi** | Finnish |
| **Svenska** | Swedish |
| **中文简体** | Simplified Chinese |
| **中文繁體** | Traditional Chinese |
| **日本語** | Japanese |
| **한글** | Korean |
| **ภาษาไทย** | Thai |

## Interface

Adjust settings for connection to a computer or television.

**USB**

Select [MTP/PTP] (default setting) or [Mass storage] for connection to computer (71) or printer (75).

**Video mode**

Choose from [NTSC] and [PAL].

**Auto transfer**

Choose [On] (default setting) to mark all new pictures for transfer to computer (74).

## Reset All

This option restores the following settings to their default values:

**Pop-up menu**

| Option | Default value |
|---|---|
| Flash mode (28) | Auto |
| Self-timer (30) | Off |
| Macro close-up (31) | Off |
| Exposure compensation (32) | 0 |

**Scene mode**

| Option | Default value |
|---|---|
| Scene menu (34) | Portrait |

**One-touch portrait menu**

| Option | Default value |
|---|---|
| Portrait effect (44) | Normal |

**Movie menu**

| Option | Default value |
|---|---|
| Movie options (60) | Small size 320 |
| Time-lapse movies (62) | 30s |
| Stop-motion movies (63) | 5 fps |
| Auto-focus mode (61) | Single AF |
| Electronic VR(61) | Off |

**Shooting menu**

| Option | Default value |
|---|---|
| Image mode (84) | Normal (3072) |
| White balance (86) | Auto |
| Continuous (88) | Single |
| Intvl timer shooting (89) | 30s |
| BSS (90) | Off |
| ISO sensitivity (91) | Auto |
| Color options (91) | Standard color |
| Electronic VR(92) | Auto |

**Setup menu**

| Option | Default value |
|---|---|
| Menus (📖 101) | Text |
| Quick startup (📖 102) | On |
| Welcome screen (📖 102) | Animation |
| Photo info (📖 106) | Auto info |
| Brightness (📖 106) | 3 |
| Date imprint (📖 107) | Off |
| Button sound (📖 109) | On |
| Shutter sound (📖 109) | 1 |
| Volume (📖 109) | Normal |
| Auto off (📖 109) | 1m |
| Auto transfer (📖 111) | On |

**Others**

| Option | Default value |
|---|---|
| Paper size (📖 77, 79) | Default |
| Slide show (📖 96) | 3s |

- Choosing [Reset all] also clears the current file number (📖 115) from the memory. Numbering will continue from the lowest number available. To reset file numbering to "0001", delete all pictures (📖 97) before selecting [Reset all].
- Picture recorded for [Welcome screen] (📖 102), settings for [Date] (📖 103), [Date counter] (📖 108), [Language] (📖 111), [USB] (📖 111), and [Video mode] (📖 111) in the setup menu will remain unaffected even if [Reset all] is performed.
  Value set for [White bal. preset] (📖 87) in the shooting menu will remain unaffected even if [Reset all] is performed.

## Ver. Firmware Version

View the current camera firmware version.



# Optional Accessories

| | |
|---|---|
| Rechargeable battery | Rechargeable Li-ion Battery EN-EL10 |
| Battery charger | Battery Charger MH-63 |
| AC adapter | AC Adapter EH-62D (connects as shown)<br>1 2 3<br>  <br>Be sure that the AC adapter's cord is properly aligned within the guide inside the battery chamber before closing the battery-chamber/memory card slot cover. If the cord is not aligned within the guide, the cover may be damaged when it is closed. |
| USB cable | USB Cable UC-E6 |
| A/V cable | Audio/Video Cable EG-CP14 |

## Approved Memory Cards

The following memory cards have been tested and approved for use in the COOLPIX S200:

| | |
|---|---|
| SanDisk | 64 MB, 128 MB, 256 MB, 512 MB, 1 GB, 2 GB[1], 4 GB[1, 2]<br>High-speed, 10-MB/s cards: 512 MB, 1 GB, 2 GB[1]<br>High-speed, 20-MB/s cards: 1 GB, 2 GB[1] |
| Toshiba | 64 MB, 128 MB, 256 MB, 512 MB, 1 GB, 2 GB[1], 4 GB[1, 2]<br>High-speed, 10-MB/s cards: 128 MB, 256 MB, 512 MB, 1 GB |
| Panasonic | 64 MB, 128 MB, 256 MB, 512 MB, 1 GB, 2 GB[1], 4 GB[1, 2]<br>High-speed, 10-MB/s cards: 256 MB<br>High-speed, 20-MB/s cards: 512 MB, 1 GB, 2 GB[1] |

[1] If the memory card will be used with a card reader or similar device, the device must support memory card specifications. If the device does not support memory card specifications, insert the memory card into the camera and connect the camera to a computer via the supplied USB cable to transfer pictures.

[2] SDHC-compliant.

Other cards have not been tested. For more details on the memory cards listed above, please contact the manufacturer.

# Image/Sound File and Folder Names

Pictures, movies, voice memos, and voice recordings are assigned file names as follows:

**DSCN0001.JPG**

Identifier
(not shown on camera monitor)

| | |
|---|---|
| Original still pictures (voice memo attachment included), movies, voice memos, voice recordings | DSCN |
| Pictures compensated in electronic VR (voice memo attachment included) | VSCN |
| Cropped copies (voice memo attachment included) | RSCN |
| Small copies (voice memo attachment included) | SSCN |
| D-Lighting copies (voice memo attachment included) | FSCN |
| Time-lapse or stop-motion movies | INTN |

Extension
(signifies the file type)

| | |
|---|---|
| Still pictures | .JPG |
| Movies | .AVI |
| Voice memos | .WAV |
| Voice recordings | |

File number
(assigned automatically in ascending order, starting with "0001")

- Files are stored in folders named with a folder number followed by a five-character identifier: "P_" plus a three-digit sequence number for pictures taken using panorama assist (e.g., "101P_001"; 40), "INTVL" for interval timer photography (e.g., "101INTVL"; 89), "SOUND" for voice recordings (e.g., "101SOUND"; 65), and "NIKON" for all other pictures (e.g., "100NIKON"). When the number of files within a folder reaches 9999, a new folder will be created. File numbers will be assigned automatically starting with "0001".
- Files copied using [Copy] > [Selected images] or [Copy sound files] > [Selected files] are copied to the current folder, where they are assigned new file numbers in ascending order starting from the largest file number in memory. [Copy] > [All images] and [Copy sound files] > [Copy all files] copy all folders from the source medium; file names do not change but new folder numbers are assigned in ascending order starting from the largest folder number on the destination medium (69, 99).
- Folders can hold up to 200 pictures; if a picture is taken when the current folder contains 200 pictures, a new folder will be created by adding one to the current folder number. If a picture is taken when the current folder is numbered 999 and contains 200 pictures or a picture numbered 9999, no further pictures can be taken until the medium is formatted (110) or a new memory card inserted.

# Caring for the Camera

To ensure continued enjoyment of this Nikon product, observe the following precautions when using or storing the device.

### ☑ Keep dry

The device will be damaged if immersed in water or subjected to high humidity.

### ☑ Do not drop

The product may malfunction if subjected to strong shock or vibration.

### ☑ Handle the lens and all moving parts with care

Do not apply force to the lens, lens cover, monitor, memory card slot, or battery chamber. These parts are easily damaged. Applying force to the lens cover could result in camera malfunction or damage to the lens. Should the monitor break, care should be taken to avoid injury caused by broken glass and to prevent the liquid crystal from the display touching the skin or entering the eyes or mouth.

### ☑ Do not point the lens at strong light sources for extended periods

Avoid pointing the lens at the sun or other strong light sources for extended periods when using or storing the camera. Intense light may cause deterioration of the CCD image sensor, producing a white blur effect in photographs.

### ☑ Keep away from strong magnetic fields

Do not use or store this device in the vicinity of equipment that generates strong electromagnetic radiation or magnetic fields. Strong static charges or the magnetic fields produced by equipment such as radio transmitters could interfere with the monitor, damage data stored on the memory card, or affect the product's internal circuitry.

### ☑ Avoid sudden changes in temperature

Sudden changes in temperature, such as occur when entering or leaving a heated building on a cold day, can cause condensation to form inside the device. To prevent condensation, place the device in a carrying case or a plastic bag before exposing it to sudden changes in temperature.

### ☑ Turn the product off before removing or disconnecting the power source

Do not remove the battery while the product is on, or while images are being recorded or deleted. Forcibly cutting power in these circumstances could result in loss of data or in damage to product memory or internal circuitry.

## The Self-Timer Lamp LED

The light-emitting diode (LED; 4, 30) used in the self-timer lamp conforms to the following IEC standard:




## The Battery

- Check the battery level when taking the camera out and charge the battery if necessary (12). Do not continue charging once the battery is fully charged, as this will result in reduced battery performance. If possible, carry a fully charged spare battery when taking pictures on important occasions.
- Do not use the battery at ambient temperatures below 0 °C (32 °F) or above 40 °C (104 °F). During charging, the temperature should be in the vicinity of 5 to 35 °C (41 to 95 °F). Note that the battery may become hot during use; wait for the battery to cool before charging. Failure to observe these precautions could damage the battery, impair its performance, or prevent it from charging normally.
- On cold days, the capacity of batteries tends to decrease. Be sure that the battery is fully charged before heading outside to take pictures in cold weather. Keep spare batteries in a warm place and exchange as necessary. Once warmed, a cold battery may recover some of its charge.
- Dirt on the battery terminals can prevent the camera from functioning.
- When the battery is not in use, remove it from the camera or battery charger and replace the terminal cover. The camera and battery charger draw minute amounts of current even when off; if left in place, the battery could be drained to the point that it no longer functions. Turning the camera on or off while the battery is exhausted can result in reduced battery life. If the battery will not be used for an extended period, store it in a cool (15 to 25 °C / 59 to 77 °F), dry place. Recharge it at least once a year and run it flat before returning it to storage.
- Replace the battery when it no longer holds a charge. Used batteries are a valuable resource. Please recycle used batteries in accordance with local regulations.

## Cleaning

| | |
|---|---|
| Lens | Avoid touching glass parts with your fingers. Remove dust or lint with a blower (typically a small device with a rubber bulb attached to one end that is pumped to produce a stream of air out the other end). To remove fingerprints or other stains that cannot be removed with a blower, wipe the lens with a soft cloth, using a spiral motion that starts at the center of the lens and working toward the edges. If this fails, clean the lens using a cloth lightly dampened with commercial lens cleaner. |
| Monitor | Remove dust or lint with a blower. To remove fingerprints and other stains, clean the monitor with a soft, dry cloth, being careful not to apply pressure. |
| Body | Use a blower to remove dust, dirt, or sand then wipe gently with a soft, dry cloth. After using the camera at the beach or seaside, wipe off any sand or salt with a dry cloth lightly dampened with fresh water, then dry thoroughly. Note that foreign matter inside the camera could cause damage not covered by the warranty. |

Do not use alcohol, thinner, or other volatile chemicals.

## Storage

Turn the camera off when not in use. Check that the power-on lamp is off before putting the camera away. Remove the battery if the camera will not be used for an extended period. Do not store the camera with naptha or camphor moth balls or in locations that:

- are next to equipment that produces strong electromagnetic fields, such as televisions or radios
- are exposed to temperatures below –10 °C (14 °F) or above 50 °C (122 °F)
- are poorly ventilated or subject to humidities of over 60%

To prevent mold or mildew, take the camera out of storage at least once a month. Turn the camera on and release the shutter a few times before putting the camera away again.

### Notes on the Monitor

- The monitor may contain a few pixels that are always lit or that do not light. This is a characteristic common to all TFT LCD displays, and does not indicate a malfunction. Images recorded using the product will not be affected.
- When framing bright subjects, vertical comet-like streaks that whiten toward either end may appear in the display. This phenomenon, known as "smear," does not appear in the final photograph and does not indicate a malfunction. Some smear may appear in movies.
- Images in the monitor may be difficult to see under bright lighting.
- The monitor is lit by an LED backlight. Should the monitor begin to dim or flicker, contact your Nikon service representative.

# Error Messages

The following table lists the error messages and other warnings displayed in the monitor, as well as the solutions for dealing with them.

| Display | Problem | Solution | |
|---|---|---|---|
| (blinks) | Clock not set. | Set clock. | 103 |
| | Battery running low. | Prepare to charge or change battery. | 12 |
| Warning! Battery exhausted. | Battery exhausted. | Charge or change battery. | 12 |
| AF● (● blinks red) | Camera cannot focus. | • Refocus.<br>• Use focus lock. | 24, 25<br>25 |
| Warning!! please wait for the camera to finish recording. | Camera cannot perform other operations until recording is complete. | Wait until message clears from display automatically when recording is complete. | 25 |
| Memory card is write protected. | Write-protect switch is in "lock" position. | Slide write-protect to "write" position. | 19 |
| This card cannot be used. | Error accessing memory card. | • Use approved card.<br>• Check that connectors are clean.<br>• Confirm that memory card is correctly inserted. | 114<br>19<br>18 |
| Warning! This card cannot be read. | | | |
| Card is not formatted. No Format | Memory card has not been formatted for use in camera. | Choose [Format] and press OK to format card, or turn camera off and replace card. | 19 |
| Out of memory. | Memory card is full. | • Choose smaller image size.<br>• Delete pictures or sound files.<br>• Insert new memory card.<br>• Remove memory card and use internal memory. | 84<br>26,53, 68, 97<br>18<br>19 |

| Display | Problem | Solution | |
|---|---|---|---|
| Image cannot be saved. | Error occurred while recording picture. | Format internal memory or memory card. | 110 |
| | Camera has run out of file numbers. | • Insert new memory card.<br>• Format internal memory or memory card. | 18<br>110 |
| | Cannot edit selected picture. | Select picture that supports crop, D-Lighting or small picture. | 47 |
| | Picture cannot be used for welcome screen. | Choose picture 640 × 480 pixels or larger, or picture taken at an image mode setting other than [16:9]. | 50, 51, 84 |
| | Cannot copy picture. | Delete pictures from destination. | 97 |
| Sound file cannot be saved. | Camera has run out of file numbers. | • Insert new memory card.<br>• Format internal memory or memory card. | 18, 110 |
| Image has already been modified. D-Lighting cannot be used. | Image cannot be enhanced using D-Lighting. | Copies from D-Lighting, crop, or small picture option cannot be adjusted using D-Lighting. | 47 |
| Cannot record movie. | Time out error while recording movie. | Choose memory card with faster write speed. | 114 |
| Memory contains no images. | • No pictures or sound file in the internal memory or memory card. | – | – |
| No sound file. | • Memory card does not contain pictures or sound file. | To copy picture or sound file from internal memory to memory card, press **MENU**. The copy option screen or copy sound file screen will be displayed. | 69,99 |

| Display | Problem | Solution | |
|---|---|---|---|
| ⓘ File contains no image data. | File not created with COOLPIX S200 | View file on computer or other device. | – |
| ⓘ This file cannot be played back. | | | |
| ⓘ All images are hidden. | Date and time are not set for pictures to be displayed by calendar mode or list by date mode. | – | – |
| ⓘ This image cannot be deleted. | Picture is protected. | Disable protection. | 98 |
| ⓘ New city is in the current time zone. | Destination in same time zone as home. | – | 103 |
| Lens error ❗ | Lens error. | Turn camera off and then on again. If error persists, contact retailer or Nikon representative. | 2, 11 |
| ⓘ Communications error | USB cable disconnected during transfer or printing. | If PictureProject displays error, click [OK] to exit. Resume operation after turning camera off and reconnecting cable. | 71, 76 |
| | [USB] option incorrect. | Choose correct [USB] option. | 71, 72 |
| | PictureProject did not start. | – | – |
| ⓘ No images are marked for transfer. | No pictures selected for transfer. | Select pictures for transfer in the playback menu and try again. | 74, 98, 111 |
| ⓘ Transfer error | Transfer error. | • Check battery level.<br>• Check that USB cable is connected. | 20<br>71 |
| System error ❗ | Error has occurred in camera's internal circuitry. | Turn camera off, remove and reinsert battery, and turn camera on. If error persists, contact retailer or Nikon representative. | 2,11, 14 |

| Display | Problem | Solution | |
|---|---|---|---|
| Printer error. Check printer status. | Running out of ink or printer error. | Check printer. After checking the ink or solving the problem, select [Resume] and press OK to resume printing.* | – |
| Printer error: check paper | Specified size of paper is not loaded in printer. | Load the specified paper, select [Resume], and press OK to resume printing.* | – |
| Printer error: paper jam | Paper has jammed in the printer. | Eject the jammed paper, select [Resume], and press OK to resume printing.* | – |
| Printer error: out of paper | No paper is loaded in printer. | Load the specified paper, select [Resume], and press OK to resume printing.* | – |
| Printer error: check ink | Ink error. | Check ink, select [Resume], and press OK to resume printing.* | – |
| Printer error: out of ink | Ink cartridge is empty. | Replace ink, select [Resume], and press OK to resume printing.* | – |
| Printer error: file corrupt | An error caused by the image file has occurred. | Select [Cancel] and press OK to cancel printing. | – |

* See the documentation provided with your printer for further guidance and information.

# Troubleshooting

If the camera fails to function as expected, check the list of common problems below before consulting your retailer or Nikon representative. Refer to the page numbers in the right-most column for more information.

### Display, Settings and Power Supply

| Problem | Cause/Solution | |
|---|---|---|
| Monitor is blank | • Camera is off.<br>• Battery is exhausted.<br>• Standby mode for saving power: press the shutter-release button halfway.<br>• When flash lamp blinks red, wait until flash has charged.<br>• Camera and TV are connected via A/V cable.<br>• Time lapse or interval timer photography in progress. | 11<br>20<br>21, 24, 109<br>29<br>70<br>62, 89 |
| Monitor is hard to read | • Adjust monitor brightness.<br>• Monitor is dirty. Clean monitor.<br>• Monitor has dimmed to save power. Monitor brightens when controls are used. | 106<br>118<br>21 |
| Camera turns off without warning | • Battery is low.<br>• Camera has turned off automatically to save power.<br>• Battery is cold. | 20<br>21, 109<br>117 |
| Date and time of recording are not correct | • Pictures recorded before clock has been set, and "Date not set" indicator blinks during shooting, will have time stamp of "00/00/0000 00:00"; movies and voice recordings will be dated "01/01/2007 00:00."<br>• Check camera clock regularly against more accurate timepieces and reset as required. | 16, 103<br>103 |
| No indicators displayed in monitor | [Hide info] is selected for [Photo info]. Select [Show info]. | 106 |
| [Date imprint] not available | Camera clock has not been set. | 16, 103 |

| Problem | Cause/Solution | |
|---|---|---|
| Date not appearing on pictures even when [Date imprint] is enabled | Date does not appear on movies or on pictures taken using , , , [Continuous], when [On] is selected for [BSS], shooting in anti-shake mode, or [Auto] is selected for [Electronic VR]. | 35, 38, 40, 42, 58, 88, 90 |
| Camera settings reset | Backup battery is exhausted; all settings were restored to their default values. | 104, 112 |

## Electronically Controlled Cameras

In extremely rare instances, unusual characters may appear in the monitor and the camera may stop functioning. In most cases, this phenomenon is caused by a strong external static charge. Turn the camera off, remove and replace the battery, and then turn the camera on again. In the event of continued malfunction, contact your retailer or Nikon representative. Note that disconnecting the power source as described above may result in the loss of any data not recorded to internal memory or the memory card at the time the problem occurred. Data already recorded will not be affected.

## Shooting

| Problem | Cause/Solution | |
|---|---|---|
| No picture taken when shutter-release button is pressed | • When camera is in playback mode, press ▶ or the shutter-release button.<br>• When menus are displayed, press MENU.<br>• Battery is exhausted.<br>• When flash lamp blinks, flash is charging. | 8, 24, 26<br>9<br>20<br>29 |
| Camera cannot focus | • The intended subject is one with which autofocus does not perform well.<br>• Focus error. Turn camera off and then on again. | 25<br>11 |
| Pictures are blurred | • Use flash.<br>• Use anti-shake mode.<br>• Use high-sensitivity shooting mode.<br>• Use electronic vibration reduction.<br>• Use BSS.<br>• Use tripod and self-timer. | 28<br>42<br>33<br>92<br>90<br>30 |

| Problem | Cause/Solution | |
|---|---|---|
| Bright specks appear in pictures taken with flash | Flash is reflecting off particles in air. Turn flash off. | 29 |
| Flash does not fire | • Flash is off.<br>• Some scene modes that cannot turn on flash are selected.<br>• Anti-shake mode is applied.<br>• 🎥 modes other than [Time-lapse movie ★] and [Stop-motion movie] are selected.<br>• [Continuous] or [Multi-shot 16] is selected for [Continuous], or [On] is selected for [BSS]. | 28<br>34<br>42<br>58<br>88, 90 |
| Optical zoom cannot be used | Optical zoom cannot be used while recording movies. | 58 |
| Digital zoom cannot be used | Digital zoom is not available when [Multi-shot 16] is selected for [Continuous], and in some scene modes. | 88 |
| [Image mode] not available | [Image mode] cannot be adjusted when [Multi-shot 16] is selected for [Continuous]. | 88 |
| No sound when shutter is released | • [Off] is selected for [Sound settings] > [Shutter sound] in setup menu.<br>• [Continuous] or [Multi-shot 16] is selected for [Continuous], or [On] is selected for [BSS] in shooting menu.<br>• 🎭 or 🏛 mode is selected.<br>• Anti-shake mode or 🎥 mode is selected. | 109<br>88, 90<br>35, 38<br>42, 58 |
| Pictures appear smeared | Lens is dirty. Clean lens. | 118 |
| Colors are unnatural | White balance does not match light source. | 86 |
| Randomly spaced bright pixels ("noise") appear in image | Shutter speed too slow. Noise can be reduced by:<br>• Using flash<br>• Specifying a lower ISO sensitivity setting<br>• Choosing scene mode with noise reduction | <br>28<br>91<br>35-40 |

| Problem | Cause/Solution | |
|---|---|---|
| Pictures are too dark (underexposed) | • Flash is off.<br>• Flash window is blocked.<br>• Subject is beyond flash range.<br>• Adjust exposure compensation.<br>• Apply high-sensitivity shooting mode, or raise the ISO sensitivity.<br>• Subject is backlit. Select ([Back light] scene mode) or use fill flash. | 28<br>22<br>28<br>32<br>33, 91<br>28, 39 |
| Pictures are too bright (overexposed) | Adjust exposure compensation. | 32 |
| Unexpected results when flash set to (auto with red-eye reduction) | In-Camera Red-Eye Fix may, in very rare cases, be applied to areas not affected by red-eye. Set flash to (auto) or (fill-flash) and try again. Note that red-eye reduction is the default setting for one-touch portrait, , and modes. | 28, 35, 36, 43 |

## Playback

| Problem | Cause/Solution | |
|---|---|---|
| File cannot be played back | • File has been overwritten or renamed by computer or other make of camera.<br>• Time lapse, stop motion, or interval timer photography in progress: pictures cannot be played back until recording is complete. | – |
| Cannot zoom in on picture | Playback zoom cannot be used with movies, small pictures, or pictures that have been cropped to below 320 × 240. | – |
| Cannot record voice memo | Voice memos cannot be appended to movies. | 52 |
| Cannot use D-Lighting, Electoric VR,crop, or small picture options | • These options cannot be used with movies.<br>• These options except Electronic VR cannot be used with pictures taken when [16:9] is applied in the image mode setting.<br>• Select picture that supports D-Lighting, Electronic VR,crop, or small picture.<br>• Camera may be unable to use these options with pictures recorded by other cameras.<br>• Other cameras may be unable to play back pictures recorded with this camera. | 47<br>47, 84<br>47<br>–<br>– |

| Problem | Cause/Solution | |
|---|---|---|
| Pictures not displayed on television | • Choose correct video mode.<br>• Memory card contains no pictures. Replace memory card. Remove memory card to play back pictures from internal memory. | 111<br>18 |
| PictureProject does not start when camera is connected | • Camera is off.<br>• Battery is exhausted.<br>• USB cable is not correctly connected.<br>• Appropriate [USB] option is not selected.<br>• Camera is not recognized by the computer.<br>• Computer is not set to launch PictureProject automatically.<br>See the supplied *PictureProject Reference Manual* (on CD) (silver) for more information on PictureProject. | 11<br>20<br>73<br>72<br>–<br>– |
| Cannot mark pictures for transfer | No more than 1,000 pictures can be marked for transfer. Click [Transfer] in PictureProject to transfer pictures. | 73 |
| Transfer marking does not appear | Pictures were marked for transfer using another model of camera. Mark pictures for transfer using COOLPIX S200. | 74, 98, 111 |
| Cannot transfer pictures | ⊛ cannot be used to transfer pictures from internal memory when [Mass storage] is selected for [USB] or if memory card is locked. Transfer pictures using the [Transfer] button in PictureProject. | 19, 71 |
| Pictures to be printed or transferred are not displayed | Memory card contains no pictures. Replace memory card. Remove memory card to print or transfer pictures from internal memory. | 18 |
| Cannot select paper size with camera | Paper size cannot be selected from the camera if the printer does not support the page sizes used by the camera or the printer automatically selects the page size. Use the printer to select page size. | 77, 79 |

# Specifications

Nikon COOLPIX S200 Digital Camera

| | |
|---|---|
| Type | Compact digital camera |
| Effective pixels | 7.1 million |
| Image sensor | 1/2.5-in. CCD; total pixels: approx. 7.41 million |
| Lens | 3× Zoom-Nikkor lens |
| Focal length | 6.3-18.9mm (equivalent with 35mm [135] format picture angle: 38-114mm) |
| f/-number | f/3.1–5.9 |
| Construction | 6 elements in 5 groups |
| Digital zoom | Up to 4x (equivalent with 35mm [135] format picture angle: approx. 456mm) |
| Vibration reduction | ElectronicVR |
| Autofocus (AF) | Contrast-detect AF |
| Focus range (from lens) | 60 cm (2 ft.) to ∞<br>Macro close-up mode: 10 cm (3.9 in.) to ∞ (when the zoom between [W] and △ positions) |
| Focus-area selection | Center |
| Monitor | 2.5 in., Approx.153,000-dot, TFT LCD with anti-reflection coating and 5-level brightness adjustment |
| Frame coverage (shooting mode) | Approx. 98% horizontal and 98% vertical |
| Frame coverage (playback mode) | Approx. 100% horizontal and 100% vertical |
| Storage | |
| Media | Internal memory (approx. 20 MB)<br>SD (Secure Digital) memory cards |
| File system | DCF, Exif 2.2, and DPOF compliant |
| File formats | Compressed: JPEG-Baseline-compliant<br>Movies: AVI<br>Sound files: WAV |
| Image size (pixels) | • 3,072 × 2,304 [High (3072★)/Normal (3072)]<br>• 2,592 × 1,944 [Normal (2592)]<br>• 2,048 × 1,536 [Normal (2048)]<br>• 1,024 × 768 [PC screen (1024)]<br>• 640 × 480 [TV screen (640)]<br>• 3,072× 1,728 (16:9) |
| ISO sensitivity | ISO 50,100, 200, 400, 800, 1000<br>Auto (auto gain to ISO 50 to 800) |

| | |
|---|---|
| Exposure | |
| Metering | 256-segment matrix, center-weighted (digital zoom), spot (digital zoom) |
| Exposure control | Programmed auto exposure with exposure compensation (–2.0 to +2.0 EV in steps of 1/3 EV) |
| Range (ISO 100) | [W]: +1.1 to +15.9 EV<br>[T]: +2.8 to +17.7 EV |
| Shutter | Mechanical and charge-coupled electronic shutter |
| Speed | 1/1000 to 4 s |
| Aperture | Electronically-controlled preset aperture |
| Range | 2 steps (f/3.1 and f/4.6 [W]) |
| Self-timer | Can be selected from 10 and 3 seconds duration |
| Built-in flash | |
| Range (approx.) (ISO sensitivity: [Auto]) | W: 0.3 to 4.6 m (11.9 in. to 15 ft. 1.1 in.)<br>T: 0.3 to 2.5 m (11.9 in. to 8 ft. 2.4 in.) |
| Flash control | Sensor flash system |
| Interface | USB |
| Video output | Can be selected from NTSC and PAL |
| I/O terminals | Audio/video out; digital I/O (USB) |
| Supported languages | Chinese (Simplified and Traditional), Czech, Danish, Dutch, English, Finnish, French, German, Indonesian, Italian, Japanese, Korean, Polish, Portuguese, Norwegian, Russian, Spanish, Swedish, Thai |
| Power source | One EN-EL10 Rechargeable Li-ion Battery (supplied), EH-62D AC Adapter (available separately) |
| Battery life* | Approx. 230 shots (EN-EL10) |
| Dimensions (W × H × D) | Approx. 91.5 × 56.5 × 18.5 mm (3.6 × 2.2 × 0.7 in.) (excluding projections) |
| Weight | Approx. 125 g (4.4 oz.) (without battery and SD memory card) |
| Operating environment | |
| Temperature | 0 to 40 °C (32 to 104 °F) |
| Humidity | Less than 85% (no condensation) |

* Based on Camera and Imaging Products Association (CIPA) standards for measuring the life of camera batteries. Measured at 23 °C (73 °F); zoom adjusted with each shot, flash fired with every other shot, image mode set to [ Normal (3072)]. Battery life may vary depending on shooting interval and length of time menus and images being displayed.

- Unless otherwise stated, all figures are for a camera with a fully-charged Rechargeable Li-ion Battery EN-EL10 operated at an ambient temperature of 25 °C (77 °F).

## EN-EL10 Rechargeable Li-ion Battery

| | |
|---|---|
| Type | Rechargeable lithium-ion battery |
| Rated capacity | 3.7 V/740 mAh |
| Operating temperature | 0 to 40 °C (32 to 104 °F) |
| Dimensions (W × H × D) | Approx. 31.5 × 39.5 × 6 mm (1.2 × 1.6 × 0.2 in.) (excluding projections) |
| Weight | Approx. 15 g (0.5 oz.) (excluding battery case) |

## MH-63 Battery Charger

| | |
|---|---|
| Rated input | 100-240V AC, 50/60 Hz, 0.07-0.045 A |
| Rated capacity | 7-10.8 VA |
| Rated output | DC 4.2V/0.55 A |
| Supported batteries | EN-EL10 Rechargeable Li-ion Battery |
| Charging time | Approx. 100 minutes when battery is fully discharged |
| Operating temperature | 0 to 40 °C (32 to 104 °F) |
| Dimensions (W × H × D) | Approx. 54 × 20 × 85 mm (2.1 × 0.8 × 3.3 in.) (excluding projections) |
| Weight | Approx. 55 g (1.9 oz.) (excluding power cable) |



**Specifications**

Nikon will not be held liable for any errors this manual may contain. The appearance of this product and its specifications are subject to change without notice.

# Supported Standards

- **DCF**: Design Rule for Camera File System is a standard widely used in the digital camera industry to ensure compatibility among different makes of camera.
- **DPOF**: Digital Print Order Format is an industry-wide standard that allows pictures to be printed from print orders stored on the memory card.
- **Exif version 2.2**: This camera supports Exif (Exchangeable Image File Format for Digital Still Cameras) version 2.2, a standard that allows information stored with photographs to be used for optimal color reproduction when images are output from Exif-compliant printers.
- **PictBridge**: A standard developed cooperatively by the digital camera and printer industries, allowing photographs to be output directly to a printer without connecting the camera to a computer.

# Index


Symbols
((✋)) (anti-shake mode)/electronic vibration button 5, 42, 49
((✋)) Anti-shake mode 42
(OK) (apply selection) button 5
Auto mode 20–27
Calendar mode 54
(delete) button 9, 26
(D-Lighting) 48
(exposure compensation) 5, 32
Help 11
High-sensitivity shooting mode 33
List by date mode 55
MENU button 9
MODE (mode) button 5, 8
Movie mode 8, 9, 58, 59
Playback mode 8, 9, 26, 27
Playback zoom 46, 50
Scene mode 9, 34
(shooting/playback) button 5, 8, 26
Thumbnail playback 45, 50
(transfer) button 71, 73, 98
Voice playback mode 67
Voice recording mode 8, 65, 101
Wait icon 119
**W** and **T** (zoom) buttons 5, 23, 31, 64, 67, 77

A
Accessories 114
AE-L 41
Anti-shake mode 42
Auto off 109
Auto transfer 111
Auto-focus mode 61
A/V cable 70
AVI 115
AV-out connect 70

B
Back light ( ) 39
Backlit subjects 28, 39
Battery 14
Battery charger 12, 114
Battery level indicator 119
Battery-chamber/memory card slot cover 5
Beach/snow ( ) 36
Best shot selector 38, 90
Blur 124
Brightness 106
BSS 93

C
Cable connector 5, 73, 76
Cleaning
  Body 118
  Lens 118
  Monitor 118
Close up ( ) 38
Close-up 31, 38
Color options 91, 93
Computer 70–74, 111
  copying pictures to 70–73
Connector cover 5
Continuous 88, 93
Copy 99
Copy ( ) 39
Crop 50
Cyanotype 91

D
Date 16–17, 103, 107
  printing 82
Date counter 108
Date imprint 107
Daylight saving time 103
DCF 131
Delete 97
Design rule for camera file system 131
Digital print order format 81–82, 131
D-Lighting 48
DPOF 131
DSCN 115

Dusk/dawn (🌇) 37
E
Electronic VR 49, 61, 92
E-mail 84
Error messages 119–122
Exif version 2.2 131
Exposure compensation 32
Extension 115
F
Face-priority AF 44
File names 115
Fill flash 28
Fireworks show (🎆) 38
Firmware version 113
Flash 28, 112
  lamp 5, 29
  mode 28
Flash mode 93
Focus 6, 24
  area 6
  face-priority 43
Folder names 115
Format 19, 110
Framing 22
FSCN 115
H
High-sensitivity shooting mode 33
I
Image mode 34, 84
Interface 70–76, 111
Internal memory 6–7, 18, 85, 110
  capacity 85
  formatting 110
ISO sensitivity 91
J
JPEG 128
JPG 115
L
Landscape (🏞) 35
Language 16, 111
Lens 4, 118
M
Macro close-up 31
Memory card 6–7, 18, 85, 114
  approved 114
  capacity of 85
  formatting 110
  Inserting and removing 18
  slot 18
Menus 101
Monitor 5, 6–7, 20, 106, 118
  brightness 106
  indicators in 6–7
Monitor settings 106
Movie menu 59
Movie mode 58
Movie options 60
  maximum movie length 60
  small size 60
  smaller size 60
  Stop-motion movie 60
  Time-lapse movie 60
  TV movie 60
Movies 58, 64
  deleting 64
  playback 64
  recording 58
Multi selector 5, 9, 10
Museum (🏛) 38
N
Night landscape (🌃) 37
O
One-touch portrait mode 43
  menu 44
  taking pictures 43
P
Panorama 40–41
Panorama assist (🎌) 40
Party/indoor (🎉) 36

PictBridge 75–81, 131
Playback 26, 45–51
    menu 94–99
    thumbnail 45
    zoom 46
Playback menu 94–99
Playback-mode selection menu 8
Power switch 4
Power-on lamp 4, 20
Print set 81, 94
Print size 85
Protect 98

Q

Quick startup 102

R

Red-eye reduction 29
Reset all 112
RSCN 115

S

Self timer 30, 93
Self-timer lamp 4, 30
Setup menu 100–113
Shooting menu 83–91
Shooting-mode selection menu 8
Shutter-release button 4
Slide show 96
Small picture 51
Smear 118
Sound settings 109
Sports (🏂) 35
SSCN 115
Strap, Camera 4
Sunset (🌅) 37
Support information 2

T

Television 70
    connecting to 70
Thumbnail playback 45
Time zone 16–17, 103, 105
Transfer 73
    mark 74, 98, 111
Transfer marking 98
    pictures for 98, 111
Tripod 5

U

USB 111
    connection 71–72, 111
USB cable 73, 76

V

Video mode 111
Voice memos 52
Voice recordings
    Copying 69
    making 65
    Playing 67
Volume 64, 68

W

WAV 115
Welcome screen 100
White balance 86, 93
    preset 87

Z

Zoom 23
    buttons 5
    indicator 6
    playback 46

Nikon

No reproduction in any form of this manual, in whole or in part (except for brief quotation in critical articles or reviews), may be made without written authorization from NIKON CORPORATION.

CE

**NIKON CORPORATION**
Fuji Bldg., 2-3 Marunouchi 3-chome,
Chiyoda-ku,Tokyo 100-8331, Japan

Printed in Japan
SB7B03(11)
*6MA27811--*